

ELECTRIC ARTICULATED LIFTS

Operator's manual

ELECTRIC ARTICULATED LIFTS

**HA12IP (HA33JE) - HA15IP (HA43JE) -
HA16PE - HA12CJ (HA33CJ) - HA12CJ+
(HA33CJ+)**



CONTENTS

1 - Operator's manual	7
2 - After Sales Service	7
3 - Compliance	8
4 - HAULOTTE Services® contact details	9

A

SAFETY PRECAUTIONS

1 - Recommendations	11
1.1 - Operator's manual	11
1.2 - Symbols used	11
1.3 - Label colors	12
2 - Pre-operation instructions	13
2.1 - General instructions	13
2.2 - Specific instructions	13
3 - Operation instructions	14
3.1 - Prohibitions	14
3.2 - Potential risks	15
3.2.1 - Risk of command system disturbance	15
3.2.2 - Risk of falling	15
3.2.3 - Risk of electrocution	16
3.2.4 - Risk of uncontrolled movement and overturning	16
3.2.5 - Risk of burns and explosion	18
3.2.6 - Risk of crushing and collision	18

B

INTERVENOR'S RESPONSIBILITY

1 - Owner's (or hirer's) responsibility	19
2 - Employer's responsibility	19
3 - Trainer's responsibility	19
4 - Operator's responsibility	19
5 - Inspection and maintenance	20

C

MACHINE LAYOUT

1 - Identification	21
2 - Main components	22
3 - Safety devices	30
3.1 - Turntable rotation pin	30
3.2 - Sliding (or swinging) intermediate guardrail	32
3.3 - Anchorage point (Please see machine configuration)	33
4 - Labels	34
4.1 - Classification plan	34
4.1.1 - Red labels	34
4.1.2 - Orange labels	36
4.1.3 - Yellow labels	38
4.1.4 - Other labels	39
4.1.5 - Green labels	41
4.2 - Identification	41

5 - Control boxes	55
5.1 - Ground control box	55
5.2 - Platform control box	63
5.3 - Various components	70

D

OPERATING PRINCIPLE

1 - Description	71
2 - Safety devices	71
2.1 - Activation of controls	71
2.2 - Drive speed	71
2.3 - Electronic variable speed drive	72
2.4 - On-board electronics	72
2.5 - Detection of internal fault	72
2.6 - Automatic engine cut-out	72
2.7 - Load limiting in the platform (if fitted)	72
2.8 - Chassis tilt	73
2.9 - Battery discharge indicator-Hour meter	73
2.9.1 - Hour meter	73
2.9.2 - Automatic reset	74
2.10 - On-board charger	74
2.10.1 - Black charger - Network 110 V - USA	74
2.10.2 - Metal charger - Network 230 V	75

E

DRIVING

1 - Recommendations	77
2 - Checks before use	77
2.1 - Visual inspections	77
2.1.1 - General mechanical functions	77
2.1.2 - Environment	79
2.2 - Functional tests	79
2.2.1 - Safety features	79
2.2.2 - Ground control box controls (emergency station)	80
2.2.3 - Platform control box controls (driving station)	81
2.3 - Periodical checks	82
2.4 - Repairs and adjustments	82
2.5 - Inspection / Testing requirements	82
3 - Operation	83
3.1 - Test procedure	83
3.1.1 - Emergency stop button operation	83
3.1.2 - Tilt sensor switch operation	84
3.1.3 - Visual and sound alarms	84
3.1.4 - Weighing system	84
3.1.5 - Movement safety end of drive contactors	84
3.2 - Operation from ground position	85
3.2.1 - Machine start-up	85
3.2.2 - Machine shutdown	85
3.2.3 - Movement control	86
3.2.4 - Other controls	88
3.3 - Operations from the platform	89
3.3.1 - Machine start-up	89
3.3.2 - Machine shutdown	89
3.3.3 - Movement control	89
3.3.4 - Other controls	96

CONTENTS

F

SPECIAL PROCEDURE

1 - Emergency lowering	97
1.1 - Principle	97
1.2 - Procedure	97
2 - Lowering for repairs	97
2.1 - Principle	97
2.2 - Procedure	97
3 - Towing	100
3.1 - Dissengaging the drive hubs	100
3.2 - Reengaging the drive hubs	101
4 - Loading and unloading	102
4.1 - Principle	102
4.1.1 - Loading by lifting	102
4.2 - Putting in transport position	103
4.3 - Unloading	106
4.4 - Warning	106
4.5 - Storage	106

G

TECHNICAL CHARACTERISTICS

1 - Main characteristics	107
2 - Overall dimensions	115
3 - Working area	119
3.1 - Machine HA12IP (HA33JE)	119
3.2 - Machine HA15IP (HA43JE)	120
3.3 - Machine HA12CJ (HA33CJ)	121
3.4 - Machine HA12CJ+ (HA33CJ+)	122
3.5 - Machine HA16PE	123
4 - AS - CE standard specificities	124
4.1 - Overload test	124
4.2 - Functional test	124
4.3 - Stability test	125
5 - Declaration of conformity	130

H

INTERVENTION REGISTER

1 - Intervention register	133
----------------------------------	------------





You have just purchased a HAULOTTE® product and we would like to thank you for your business.

1 - Operator's manual

As stated on the delivery slip, this manual is one of the documents in the on-board document holder provided upon delivery of your HAULOTTE® machine.

The operator manual is a translation of the original instructions.

Safe operation of this product can only be assured if you follow the operating instructions contained in this manual.

We would particularly like to draw your attention to 2 essential points :

- Compliance with safety instruction (machine, use, environment)
- Use of the equipment within the performance limits.



With regard to the designation of our equipment, we stress that this is purely for commercial purposes and not to be confused with the technical characteristics. Only the tables of technical characteristics should be used to study the suitability of the equipment for the intended use.

2 - After Sales Service

Our HAULOTTE Services® After Sales Service is at your disposal throughout your machine's service life to ensure optimal use of your HAULOTTE product..

- When contacting our After Sales Service, ensure that you provide the machine model and serial number.
- When ordering any consumables or spare parts, please use this manual and the Haulotte Essential catalogue to receive your genuine HAULOTTE spare parts, your only guarantee of parts interchangeability and correct machine operation..
- If there is an equipment malfunction involving a HAULOTTE® product, then contact HAULOTTE Services® immediately even if the malfunction does not involve material and/or bodily damage..
- HAULOTTE® must be informed in the event of an incident that either involves one of these products or has caused bodily injury or significant deterioration of property (personal property or the product); contact HAULOTTE Services® immediately (See : HAULOTTE Services® contact details)

3 - Compliance

We would like to remind you that HAULOTTE® complies with the provisions of any applicable directives applicable to this type of machine.

HAULOTTE advises you that NO modifications carried out without the written permission of HAULOTTE® will void the HAULOTTE warranty..

HAULOTTE® cannot be held liable for any changes to the technical specifications contained in this manual.

HAULOTTE® reserves the right to alter technical specifications and to make improvements or modifications to the machine without modifying this manual.



Certain options can modify the machine's operating characteristics and its associated safety. If your machine was originally delivered with options fitted, replacing a safety component associated with a particular options not require any particular precautions other than those associated with the installation itself (static test).

Otherwise, it is essential to follow the manufacturer's recommendations below :

- **Installation by authorised HAULOTTE® personnel only.**
- **Update the manufacturer's identification plate.**
- **Have stability tests carried out by a certified agency/competent person.**
- **Ensure label compliance.**

4 - HAULOTTE Services® contact details

HAULOTTE Services® contact details

	HAULOTTE FRANCE PARC DES LUMIERES 601 RUE NICEPHORE NIEPCE 59800 SAINT-PIERRE TECHNICAL Department: +33 (0)820 200 089 SPARE PARTS : +33 (0)820 205 344 FAX : +33 (0)4 72 88 01 43 E-mail : haulottefrance@haulotte.com www.haulotte.fr		HAULOTTE ITALIA VIA LOMBARDIA 15 20098 SAN GIULIANO MILANESE (MI) TEL: +39 02 98 97 01 FAX: +39 02 9897 01 25 E-mail : haulotteitalia@haulotte.com www.haulotte.it		
	HAULOTTE HUBARBEITSBÜHNEN GmbH AN DER MÖHLINHALLE 1 D-79189 BAD MÜNZINGEN-HAUSEN TEL : +49 (0) 7633 806 92-0 FAX : +49 (0) 7633 806 92-18 E-mail : haulotte@de.haulotte.com www.haulotte.de		HAULOTTE VOSTOK, OOO 3, ZHUKOVSKOGO STREET DOLGOPRUDNY 141700 MOSCOW REGION RUSSIAN FEDERATION TEL/FAX : +7 495 579 57 17 E-mail : nkova@haulottevostok.ru www.haulotte-international.com		HAULOTTE DO BRASIL AV. CECI, 608 - B 13 CEP: 06460-120 - TAMBORE BARUERI - SÃO PAULO - BRASIL TEL : +55 11 4208 4208 FAX : +55 11 4191 4677 E-mail : haulotte@haulotte.com.br www.haulotte.com.br
	HAULOTTE IBERICA C/ARGENTINA Nº 13 - P.I. LA GARENA 28806 ALCALA DE HENARES MADRID TEL : +34 902 886 455 TEL SAT : +34 902 886 444 FAX : +34 91 656 97 81 E-mail : iberica@haulotte.com www.haulotte.es		HAULOTTE POLSKA Sp. z o.o. UL. GRANICZNA 22 05-090 RASZYN - JANKI TEL : +48 22 720 06 80 FAX : +48 22 720 35 06 E-mail : haulottepolska@haulotte.com www.haulotte.pl		HAULOTTE MÉXICO, Sa de Cv Calle 9 Este, Lote 18, Cívica, 3utepec, Morelos CP 62500 Cuernavaca México TEL : +52 77 7321 7923 FAX : +52 77 7516 8234 E-mail : haulotte.mexico@haulotte.com www.haulotte-international.com
	HAULOTTE PORTUGAL ESTRADA NACIONAL N.º 10 KM. 140 - LETRA K 2695 - 066 BOADELA LIS TEL : +351 21 995 98 10 FAX : +351 21 995 98 19 E-mail : haulotteportugal@haulotte.com www.haulotte.es		HAULOTTE SINGAPORE Pte Ltd. No.26 CHANGI NORTH WAY, SINGAPORE 498812 Parts and service Hotline: +65 6546 6179 FAX : +65 6536 3969 E-mail : haulotteasia@haulotte.com www.haulotte.sg		HAULOTTE MIDDLE EAST FZE PO BOX 203881 Dubai Airport Free Zone DUBAI United Arab Emirates TEL : +971 (0)4 299 77 35 FAX : +971 (0) 4 299 60 28 E-mail : haulottemiddle-east@haulotte.com www.haulotte-international.com
	HAULOTTE SCANDINAVIA AB Talljägärdagatan 12 431 53 Mölndal SWEDEN TEL : +46 31 744 32 90 FAX : +46 31 744 32 99 E-mail : info@se.haulotte.com spares@se.haulotte.com www.haulotte.se		HAULOTTE TRADING (SHANGHAI) Co. Ltd. #7 WORKSHOP No 191 HUA JIN ROAD MIN HANG DISTRICT SHANGHAI CHINA 201108 TEL : +86 21 6442 6610 FAX : +86 21 6442 6619 E-mail : haulottehai@haulotte.com www.haulotte.cn		HAULOTTE ARGENTINA Ruta Panamericana Km. 34,300 (Ramal A Escobar) 1615 Gran Bourg (Provincia de Buenos Aires) Argentina TEL: +54 033 27 45 21 91 FAX: +54 033 27 45 72 19 E-mail : haulotteargentina@haulotte.com www.haulotte-international.com
	HAULOTTE UK Ltd STAFFORD PARK 6 TELFORD - SHROPSHIRE TF3 3AT TEL : +44 (0)1952 292753 FAX : +44 (0)1952 292758 E-mail : salesuk@haulotte.com www.haulotte.co.uk		HAULOTTE GROUP / BILJAX 125 TAYLOR PARKWAY ARCHBOLD, OH 43502 - USA TEL : +1 419 445 8915 FAX : +1 419 445 0367 Toll free : +1 800 537 0540 E-mail : sales@us.haulotte.com www.haulotte-usa.com		HAULOTTE DO BRASIL AV. CECI, 608 - B 13 CEP: 06460-120 - TAMBORE BARUERI - SÃO PAULO - BRASIL TEL : +55 11 4688 1295 / +55 11 4208 4208 FAX : +55 11 4191 4677 E-mail : americatina@haulotte.com www.haulotte-international.com
	HAULOTTE NETHERLANDS BV BRIELTJENSPOLDER 30 4921 PJ MADE TEL : +31 (0) 162 670 707 FAX : +31 (0) 162 670 710 E-mail : info@haulotte.nl		HAULOTTE AUSTRALIA PTY Ltd 46 GREENS ROAD DANDENONG - VIC - 3175 TEL : +61 (0)3 9792 1000 FAX : +61 (0)3 9792 1011 E-mail : sales@haulotte.com.au		

A - Safety precautions

1 - Recommendations

1.1 - OPERATOR'S MANUAL

This operators manual is specific to the HAULOTTE® products listed on the cover page of this manual..



The operator manual does not replace the basic training required for all worksite equipment operators.

HAULOTTE® has compiled this manual to assist in safe and efficient operation of the products covered by the manual.



This manual must be kept on the machine (or in the cab in its storage case. The manual must be available to all operators and must be kept in good condition. Additional copies can be ordered from HAULOTTE Services®.

1.2 - SYMBOLS USED

Symbols are used to alert the operator to safety precautions or to highlight practical information.

Legend

Symbol	Meaning
	Danger : Risk of injury or death (work safety)
	Caution : Risk of material damage (work quality)
	Prohibition relating to work safety and quality
	Reminder : No identified risk, but a reminder of the need for common sense, good practice or pre-action prerequisites
	Cross-reference to another part of the manual (see section or sheet)
	Cross-reference to another manual (see manual)
	Cross-reference to repairs (contact HAULOTTE Services®)
N.B. :	Additional technical information

A

- Safety precautions

1.3 - LABEL COLORS

The potential dangers and any specific regulations are indicated around the product by labels and identification plates.



The labels must be kept in good condition. Additional labels can be obtained from HAULOTTE Services®.

Familiarize yourself with the labels and their respective color codes.

Label color code-CE - AS

Labels	Color	Meaning
	Red	Potentially fatal danger
	Orange	Risk of serious injury
	Yellow	Risk of material damage and/or minor injury
	Other	Additional technical information

Label color code-ANSI - CSA

Labels	Color	Meaning
	Red	Potentially fatal danger
	Orange	Risk of serious injury
	Yellow	Risk of material damage and/or minor injury
	Other	Additional technical information
	Green	CSA maintenance operation or information

A

- Safety precautions

2 - Pre-operation instructions

2.1 - GENERAL INSTRUCTIONS



- The employer has the obligation to issue a driving permit to the operator.
- The employer is obliged to inform the operator of the local regulations.



Do not operate the product in the following situations :

- On soft, unstable or cluttered ground.
- With wind blowing faster than the permissible limit. Check the maximum value in the technical characteristics (📖 Section G 1- Main characteristics). Consult the Beaufort scale (📖 Section A 3.2.4- Risk of uncontrolled movement and overturning).
- Close to power lines. Respect the safety distance (📖 Section A 3.2.3- Risk of electrocution).
- At ambient temperatures higher than 45 °C(113 °F) and lower than -15 °C(5 °F) . Consult HAULOTTE® if it is necessary to work outside this range.
- In an explosive atmosphere.
- During storms (risk of lightning).
- In the presence of strong electromagnetic fields (radar, etc ...).

N.B.-:YOU ARE ADVISED TO USE THE MACHINE UNDER "NORMAL" CLIMATIC CONDITIONS.. IF YOU NEED TO USE THE MACHINE IN CLIMATIC CONDITIONS LIKELY TO CAUSE DETERIORATION (HUMIDITY, TEMPERATURES OUTSIDE THE RECOMMENDED RANGES, SALINITY, CORROSIVENESS, ATMOSPHERIC PRESSURE), CONTACT HAULOTTE SERVICES®. REDUCE INTERVALS BETWEEN SERVICING.

N.B.-:WHILST THE MACHINE IS NOT IN USE, CARE MUST BE TAKEN TO ENSURE THAT IF THE MACHINE IS NOT LOCKED IN A SECURE LOCATION, THAT THE UNIT KEY SWITCH IS REMOVED TO PREVENT UNAUTHORISED USE OF THE MACHINE.

2.2 - SPECIFIC INSTRUCTIONS



Do not operate the product in the following situations :

- If the load in the platform exceeds the maximum load authorized. Check the maximum value in the technical characteristics (📖 Section G 1- Main characteristics).
- If the ground slope is greater than the permissible limit. Check the maximum value in the technical characteristics (📖 Section G 1- Main characteristics).
- For HA16PE only : In a non-ventilated area as the exhaust gases are toxic.
- At night unless the machine is equipped with the optional light.
- If the number of persons exceeds the permissible limit. Check the maximum value in the technical characteristics (📖 Section G 1- Main characteristics)
- If the side force is greater than the permissible force. Check the maximum value in the technical characteristics (📖 Section G 1- Main characteristics)

A

- Safety precautions

3 - Operation instructions



It is preferable to operate the machine on flat, consolidated ground (tarmac, concrete, etc.).

3.1 - PROHIBITIONS



- Never use a faulty machine (hydraulic leaks, worn tires, malfunction).
- Never operate the machine controls suddenly.
- Never place the machine against a structure to hold that structure in place.
- Never use the machine to tow other machines or to drag materials.
- Never expose the batteries or electrical components to water (pressure cleaner, rain).
- Never disable the safety devices.
- Do not make contact with a fixed or mobile obstacle. The contact can cause premature deterioration of the structure and lead to the corruption of certain safety elements.
- Do not climb onto the covers.
- Never use the machine with only an operator in the platform. It must be used by 2 operators.
- Never use the machine when the platform is cluttered.
- Never increase the surface area of the platform by using floor extensions or accessories not authorized by HAULOTTE®.
- Never leave the hydraulic cylinders fully extended or retracted before switching off the machine, or during an extended stop period.



- Never use the machine with material or objects hanging from the guardrail or the boom.
- Never use the machine with elements that can increase the wind force (panels).
- Never increase the working height by using attachments (ladder).
- Never use the guardrail as a means of access for climbing in or out of the platform. The basket can be easily accessed in its low position. For machines fitted with : Steps have been provided for this purpose where required.
- Never climb on the guardrail.
- Never use the machine without fully lowering the sliding midrail or without closing the platform entry gate.
- Never use the machine as a crane, material lift or elevator.
- Never use the machine for any other purpose than to transport people, their tools and material to the desired place.
- Never drive fast in narrow or cluttered areas. Keep speed under control in bends.
- Never tow the machine over extended distances (it must be transported on a trailer). In case of a machine failure, it is possible to tow it to load it onto a trailer ( Section F 3 Towing).

A

- Safety precautions

3.2 - POTENTIAL RISKS

3.2.1 - Risk of command system disturbance

Risk of disrupted movement. Maintain clearance from high voltage lines or magnetic fields.

3.2.2 - Risk of falling

When in the platform, respect the following instructions :

- Carry individual protection equipment adapted to the work conditions and local rules.
- Avoid contact with fixed or mobile obstacles (other machines).
- Ensure that the adjustable midrail is closed (low position and against the guardrails).
- Ensure that the gate is closed and locked (For machines fitted with).
- Hold on securely to the guardrails during elevation and driving.
- Do not sit, stand, or climb on the platform guard rails.
- Ensure that guard rails are correctly installed and locked.
- Always keep your feet firmly on the floor of the platform.
- Remove any trace of oil or grease from the steps, floor, handrail and the guardrails.
- Keep the floor of the platform free of debris.
- Do not leave the platform until it is fully in its stowed position.
- Do not climb on to the platform if the machine is not in the stowed position.



To climb up or climb down from the platform :

- The machine must be completely stowed.
- Face the machine to access the entry opening to the platform
- Keep 3 support points between the steps and the guardrail



A - Safety precautions

3.2.3 - Risk of electrocution

The machine is not electrically insulated and does not offer any insulation protection.



The risks of electrocution are high in the following situations :

- Close to live power lines, consider the movement of the machine and the sway of the electric power lines particularly in windy conditions.
- In the event that you were to make accidental contact with a high voltage line, wait for the power to the line to be switched off before operating the machine.
- During storms.

Never use the machine as a welding earth.

Maintain a minimum safe distance with regard to power lines and electrical devices.

Respect the local rules and the minimum safety distance from power lines..

Minimum safety distance

Electric voltage	Minimum safety distance	
	Mètre	Feet
0 - 300 V	Avoid contact	
300 V - 50 kV	3	10
50 - 200 kV	5	15
200 - 350 kV	6	20
350 - 500 kV	8	25
500 - 750 kV	11	35
750 - 1000 kV	14	45

N.B.:-THIS TABLE IS APPLICABLE, EXCEPT WHEN THE LOCAL REGULATIONS ARE MORE STRICT.

3.2.4 - Risk of uncontrolled movement and overturning

When in the platform, respect the following instructions :



- Before operating the machine on any indoor or outdoor surface (premises, bridge, truck, etc.), check that the surface is capable of supporting the combined machine weight and platform capacity. Check the maximum value in the technical characteristics (📄 Section G 1- Main characteristics).
- During motion direction reversal from the platform or ground control box, the joysticks or switches must be stopped in neutral position before reversing the direction of motion.
- Taking note of the overall load dimensions and weight, place the loads in the centre of the platform or distribute them in a uniform manner.
- Remain vigilant of driving direction reversal at the platform. Check the driving direction with the help of the red or green arrow on the chassis relative to the red and green arrows on the platform control box.
- Always ensure that the chassis is never driven any closer than 1 m(3 ft3 in) m to holes, bumps, tilts, obstructions, debris and ground coverings that may hide holes and other dangers.
-  Do not drive the machine on slopes or tilts beyond the design limits. Check the maximum value in the technical characteristics(📄 Section G 1- Main characteristics).

A

- Safety precautions



- If the tilt alarm sounds when the platform is raised, lower platform completely, then reposition machine onto level ground before raising platform.
- Do not travel down slopes at high speed.
- Do not use the machine (elevation and travel) on an incline greater than that permitted by the slope sensor.
- Do not drive in reverse (direction opposite the field of vision).
- Do not pull or push objects with the boom.
- Never use the machine in winds exceeding the permissible limit.
- Do not increase the surface area exposed to wind. The greater the surface area exposed, the more unstable the machine becomes.

N.B.:-THE BEAUFORT SCALE MEASURES THE WIND FORCE WITH A GRADUATION SYSTEM. A WIND SPEED RANGE AT 10 M(32 FT9 IN) ABOVE FLAT, CLEAR LAND IS ASSOCIATED WITH EACH DEGREE.

Beaufort scale

Force	Meteorological description	Observed effects	m/s	km/h	mph
0	Calm	Smoke rises vertically.	0 - 0,2	0 - 1	0 - 0,62
1	Very light breeze	Smoke indicates the wind direction.	0,3 - 1,5	1 - 5	0,62 - 3,11
2	Light breeze	Wind felt on the face. Leaves rustle. Weather vanes turn.	1,6 - 3,3	6 - 11	3,72 - 6,84
3	Slight breeze	Leaves and small branches in constant movement. Flags move slightly.	3,4 - 5,4	12 - 19	7,46 - 11,8
4	Nice breeze	Dust and loose papers fly. Small branches bend.	5,5 - 7,9	20 - 28	12,43 - 17,4
5	Nice breeze	Small trees sway. Crested wavelets form on inland waters.	8,0 - 10,7	29 - 38	18,02 - 23,6
6	Cool wind	Large branches shake. Power lines and chimneys 'sing'. It is difficult to use an umbrella.	10,8 - 13,8	39 - 49	24,23 - 30,45
7	Strong cool wind	All trees shake. Walking against the wind becomes difficult.	13,9 - 17,1	50 - 61	31 - 37,9
8	Squall	Some branches break. Generally we cannot walk against the wind.	17,2 - 20,7	62 - 74	38,53 - 45,98
9	Strong squall	The wind causes slight damage to buildings. Tiles and chimney stacks are blown off.	20,8 - 24,4	75 - 88	46,60 - 54,68

A - Safety precautions

3.2.5 - Risk of burns and explosion



For any intervention on the power sources, wear glasses and protective clothes (acid spray).

N.B.:-ACID IS NEUTRALISED WITH SODIUM BICARBONATE AND WATER.



- Do not work in an explosive or flammable atmosphere (spark, flame, etc.).
- Do not touch the hot parts of the hydraulic power source (engine, filters, etc.).
- Do not bridge the battery terminals with metallic objects.
- Do not service the battery close to a spark, naked flame, glowing tobacco (emissions of gas).



- For HA16PE only : Do not fill up the fuel tank, when the engine is running and/or close to a naked (open) flame.

3.2.6 - Risk of crushing and collision

When in the platform, respect the following instructions :

- During operation, keep all the parts of the body inside the platform.
- Adjust the movement speed to the ground conditions (traffic, slope, etc.).
- Respect stopping distances after the controls are released :
 - 3 m(9 ft10 in) at high speed.
 - 1 m(3 ft3 in) at low speed.
- To position the machine close to obstacles, use the raise controls (arm, boom, etc.) instead of the drive controls.
- Ensure there are no obstacles (structure) in the work area.
- When driving, position the platform so as to provide the best visibility possible.
- Always use another person to guide machine movements in case of poor visibility.
- All the personnel in the platform or on the within the vicinity of the machine must wear Personal Protection Equipment (safety helmet, etc.).
- When lifting or lowering the basket and during driving, the operator must check that the area above, below and to each side of the machine are clear.
- When moving the machine, ensure that the machine operating areas is free of persons and obstacles.



Do not operate other machines (crane, platform, etc.) in the work area.

Take account of the distance, reduced visibility and blind spots during use of the machine.

B

- Intervenor's responsibility

1 - Owner's (or hirer's) responsibility

The owner (or hirer) has the obligation to inform operators of the instructions contained in the Operator Manual.

The owner (or hirer) has the obligation to renew all manuals or labels that are either missing or in bad condition. Additional copies can be ordered from HAULOTTE Services®.

The owner (or hirer) is responsible for applying the local regulations regarding operation of the machine.

2 - Employer's responsibility

. The employer has the obligation to issue a driving permit to the operator.

N.B.-:IN ACCORDANCE WITH THE REGULATION IN THE COUNTRY WHERE THE MACHINE IS OPERATING, THE USER MUST BE AUTHORIZED TO DRIVE BY THE DOCTOR OF LABOUR MINISTRY.



Forbid anyone from operating the machine who is :

- Under the influence of drugs, alcohol, etc..
- subject to fits, loss of motor skills, dizziness, etc..

3 - Trainer's responsibility

The trainer must be qualified to provide training to operators in accordance with applicable local regulations. The training must be given in an obstacle-free area until the trainee is considered competent as defined by the training program undertaken.

4 - Operator's responsibility

The operator must read and understand the contents of this manual and the labels affixed on the machine.

The operator must inform the owner (or hirer) if the manual or any labels are missing or in poor condition, and of any malfunction of the machine.

The operator may only operate the machine for the purpose intended by the manufacturer.



Only authorized and qualified operators may operate HAULOTTE® machines.

All operators must become familiar with and fully understand the emergency controls and how to operate the machine in an emergency as a component of their formal operator training.

The operator has the obligation stop using the machine in the event of malfunction or safety problems on the machine or in the work area and report the problem to his/her supervisor.

B

- Intervenor's responsibility

5 - Inspection and maintenance

The inspection and maintenance table below, identifies the role and the responsibilities of each party in periodical machine maintenance..



If the machine is operated in a hostile environment or intensively, increase the frequency of maintenance.

Inspections and maintenance

Type of intervention	Frequency	Person-in-charge	Intervenor	Reference document
Pre-delivery inspection	Before each delivery of sold, hired or resold equipment	Owner (or hirer)	Qualified HAULOTTE Services® technician	Operator's manual
Pre-operation inspection	Before operation or when the operator changes	Operator	Operator	Operator's manual
Periodical preventive maintenance	At the specified intervals (250 hours or 1 year)	Owner (or hirer)	On-site technician or qualified HAULOTTE Services® technician	Maintenance book
Periodical visit	2 times a year or at the latest 6 months after the last periodic visit, and according to the local regulations	Owner (or hirer)	Organization or technician approved by the employer or by the intermediary of HAULOTTE Services® in accordance with the HAULOTTE Services® contract	Maintenance book

C - Machine layout

1 - Identification

The manufacturers identification plate fixed on the chassis bears all pertinent information to identify the machine (Please see machine configuration).

on HA12CJ (HA33CJ) and HA12CJ+ (HA33CJ+) only :

The manufacturer's identification plate fixed on the side of the riser arm features all the necessary information to identify the machine.



For any request for information, intervention or spare parts, specify the type and serial number of the machine.

Identification plate CE - AS

A3

Haulotte GROUP		CE
HAULOTTE GROUP, La Péronnière, BP9 42152 L'Horme - France		
EQUIPMENT		
TYPE		
SERIAL N°		
TOTAL WEIGHT		
YEAR OF MANUFACTURE		
POWER SOURCE (Fuel/gas/LPG)		
POWER SOURCE (electric)		
MAXIMUM LOAD		
NUMBER OF PERSONS + LOAD		
MAXIMUM PLATFORM HEIGHT		
MAXIMUM PLATFORM REACH		
LATERAL FORCE MAX.		
SLOPE OPERATION MAX.		
MADE IN FRANCE, THIS MACHINE HAS BEEN MANUFACTURED IN COMPLIANCE WITH:		

2420318102 c

Identification plate ANSI - CSA

A3


Haulotte GROUP		HAULOTTE GROUP, La Péronnière, BP9 42152 L'Horme - France
EQUIPMENT		
TYPE		
SERIAL N°		
TOTAL WEIGHT		
YEAR OF MANUFACTURE		
POWER SOURCE (Fuel/gas/LPG)		
POWER SOURCE (electric)		
MAXIMUM LOAD		
NUMBER OF PERSONS + LOAD		
MAXIMUM PLATFORM HEIGHT		
MAXIMUM PLATFORM REACH		
LATERAL FORCE MAX.		
SLOPE OPERATION MAX.		
MADE IN FRANCE, THIS MACHINE HAS BEEN MANUFACTURED IN COMPLIANCE WITH:		

2420318102 b

C - Machine layout

2 - Main components

HA12IP (HA33JE) - Major Component Location Diagram



C


- Machine layout

HA12IP (HA33JE) - Description of the components

Marking	Description
C1	Chassis
C4	Jib
C5	Platform support incorporating load limiter
C6	Platform
C7	Platform control box
C8	Level compensation cylinder
C9	Upper boom
C10	Slew ring
C11	Turntable assembly
C12	Side cover
C16	Lower arm
C20	Tie-down (and/or lifting) points
C27	Ground control box
C28	Slope sensor switch
C32	Turntable rotation gearbox
C33	Counterweight
C34	Drive wheels
C35	Document holder
C43	Turntable rotation lock pin
C47	Battery isolation switch
C56	Battery box
C92	Hydraulic filter
C93	Electric pump unit
C136	Steer wheels
C137	Electric drive motor
C138	Battery charger
C139	Electronic variable speed drive
C153	Hydraulic oil tank

C - Machine layout

HA15IP (HA43JE) - Major Component Location Diagram



C


- Machine layout

HA15IP (HA43JE) - Description of the components

Marking	Description
C1	Chassis
C4	Jib
C6	Platform
C7	Platform control box
C8	Level compensation cylinder
C9	Upper boom
C10	Slew ring
C11	Turntable assembly
C12	Side cover
C16	Lower arm
C20	Tie-down (and/or lifting) points
C27	Ground control box
C28	Slope sensor switch
C32	Turntable rotation gearbox
C33	Counterweight
C34	Drive wheels
C35	Document holder
C43	Turntable rotation lock pin
C47	Battery isolation switch
C56	Battery box
C92	Hydraulic filter
C93	Electric pump unit
C136	Steer wheels
C137	Electric drive motor
C138	Battery charger
C139	Electronic variable speed drive
C153	Hydraulic oil tank

C - Machine layout

HA12CJ (HA33CJ) - HA12CJ+ (HA33CJ+) - Major Component Location Diagram



C


- Machine layout

HA12CJ (HA33CJ) - HA12CJ+ (HA33CJ+) - Description of the components

Marking	Description
C1	Chassis
C4	Jib
C6	Platform
C7	Platform control box
C8	Level compensation cylinder
C9	Upper boom
C10	Slew ring
C11	Turntable assembly
C12	Side cover
C16	Lower arm
C20	Tie-down (and/or lifting) points
C27	Ground control box
C28	Slope sensor switch
C33	Counterweight
C34	Drive wheels
C35	Document holder
C42	'Enable Switch' pedal
C43	Turntable rotation lock pin
C47	Battery isolation switch
C56	Battery box
C104	Harness anchorage point
C136	Steer wheels
C138	Battery charger
C139	Electronic variable speed drive
C151	Cable carrier cat track
C152	Electric drive motor - Brake - Wheel reducer
C153	Hydraulic oil tank

C - Machine layout

HA16PE - Major Component Location Diagram



C

- Machine layout

HA16PE - Description of the components

Marking	Description
C1	Chassis
C3	Rear drive and/or steer wheel
C4	Jib
C5	Platform support incorporating load limiter
C6	Platform
C7	Platform control box
C8	Level compensation cylinder
C9	Upper boom
C10	Slew ring
C11	Turntable assembly
C12	Side cover
C14	Hydraulic drive motor and reducer
C15	Right side cover (hydraulic oil tank and fuel tank)
C16	Lower arm
C17	Left side cover (engine, pump and starter battery)
C20	Tie-down (and/or lifting) points
C27	Ground control box
C28	Slope sensor switch
C32	Turntable rotation gearbox
C33	Counterweight
C35	Document holder
C43	Turntable rotation lock pin
C47	Battery isolation switch
C56	Battery box
C136	Steer wheels
C138	Battery charger
C153	Hydraulic oil tank

C - Machine layout


3 - Safety devices

3.1 - TURNTABLE ROTATION PIN

The turntable rotation pin allows turntable locking during machine transportation



After each transportation, remove the turntable rotation locking pin.



Turntable rotation locking pin (Please see machine configuration)



Turntable rotation locking pin (Please see machine configuration)



Turntable rotation locking pin (Please see machine configuration)



C - Machine layout

Turntable rotation locking pin (Please see machine configuration)



Turntable rotation locking pin (Please see machine configuration)



A

B

C

D

E

F

G

H

I


C - Machine layout

3.2 - SLIDING (OR SWINGING) INTERMEDIATE GUARDRAIL

The platform is comprised of guardrails and a sliding mid-rail facilitating platform access.



Do not restrain the sliding midrail to the guard rail.



C

- Machine layout

3.3 - ANCHORAGE POINT (PLEASE SEE MACHINE CONFIGURATION)

The machine is equipped with harness anchorage points which accept a single harness per anchorage point. The anchorage points are identified by the presence of the Anchorage point label.



If the local regulation imposes the wearing of a harness, use the approved anchorage points.



C - Machine layout

4 - Labels


4.1 - CLASSIFICATION PLAN

4.1.1 - Red labels




The red labels indicate a potentially fatal danger.

Common labels




C - Machine layout


Specific labels HA12IP (HA33JE)




Specific labels HA12IP (HA33JE) Option Wide platform



Specific labels HA15IP (HA43JE)




Specific labels HA12CJ (HA33CJ)




C - Machine layout

Specific labels HA12CJ+ (HA33CJ+)



Specific labels HA16PE




4.1.2 - Orange labels



The orange labels indicate a risk of serious injury.

Common labels - CE



C - Machine layout

Common labels - AS



Common labels - ANSI - CSA




C - Machine layout

4.1.3 - Yellow labels




The yellow labels indicate a risk of material damage and/or minor injury.

Common labels




Specific HA12CJ (HA33CJ) and HA12CJ+ (HA33CJ+) labels




C - Machine layout

Specific labels HA16PE



Specific labels AS



Specific labels AS : HA16PE




Specific labels ANSI



C - Machine layout

Specific labels, optional




4.1.5 - Green labels



Green labels indicate maintenance, operations or information(CSA standard).

4.2 - IDENTIFICATION

HA12IP - HA15IP (HA33JE - HA43JE) / HA16PE - Locations - Standards CE and AS



C - Machine layout

Label descriptions-Standards CE and AS

Color	Marking	Description	Quantity	HA12IP (HA33JE)	HA15IP (HA43JE)
Red	R1	Height of the floor and load	2	3078145890	3078152960
Red	R1	Height of the floor and load(Optional)	2	3078149410	
Red	R2	Travel direction	1	3078145070	3078145070
Red	R3	Risk of crushed hands	2	3078143620	3078143620
Red	R4	Risk of body crushing	2	3078143630	3078143630
Red	R5	Danger of electrocution	1	3078143490	3078143490
Red	R6	Do not interchange	1	For AS standard only : 3078145180	For AS standard only : 3078145180
Red	R7	Do not park in the work area	1	3078143550	3078143550
Red	R8	Close the sliding mid-rail	1	3078153510	3078153510
Red	R9	Wheel load	4	For AS standard only : 3078151550	For AS standard only : 3078152060
Red	R15	Harness use	1	For AS standard only : 3078144520	For AS standard only : 3078144520
Red	R16	Load strength on each slings	4	For AS standard only : 3078144490	For AS standard only : 3078144490
Red	R17	Do not travel down slopes at high speed	1	CE standard : 3078144490 AS standard : 3078144360	CE standard : 3078144490 AS standard : 3078144360
Red	R21	Protective clothing required	1	3078143610	3078143610

C

- Machine layout

Color	Marking	Description	Quantity	HA12IP (HA33JE)	HA15IP (HA43JE)
Orange	O1	Operation instructions	1	In french CE standard : 3078143420	In french CE standard : 3078143420
				In english Standards CE and AS : 3078144560	In english Standards CE and AS : 3078144560
				In german CE standard : 3078143440	In german CE standard : 3078143440
				In spanish CE standard : 3078143430	In spanish CE standard : 3078143430
				In italian CE standard : 3078143460	In italian CE standard : 3078143460
				In danish CE standard : 3078144940	In danish CE standard : 3078144940
				In portuguese CE standard : 3078145830	In portuguese CE standard : 3078145830
				In finish CE standard : 3078145540	In finish CE standard : 3078145540
				In swedish CE standard : 3078145940	In swedish CE standard : 3078145940
				In dutch CE standard : 3078143470	In dutch CE standard : 3078143470
				In english Standards CE and AS : 307P227220	In english Standards CE and AS : 307P227220
Orange	O1	Operation instructions White background	1		
Yellow	J1	Greasing the turntable rotation gear	1	3078143570	3078143570
Yellow	J2	Remove the blocking pin before rotating	1	3078143530	3078143530
Yellow	J3	Do not place your foot on the cover	2	3078143640	3078143640
Yellow	J4	Do not use the machine as a welding earth	1	3078143600	3078143600
Yellow	J6	Verification of tilt operation	1	3078144650	3078144650
Yellow	J10	Socket	1	CE standard : 3078143540	CE standard : 3078143540
				AS standard : 3078144570	AS standard : 3078144570
Yellow	J13	Battery verification	1	3078143510	3078143510
Yellow	J14	Using the machine during battery charging is forbidden	1	3078143560	3078143560
Yellow	J15	Battery charger socket	2	For AS standard only : 3078144390	For AS standard only : 3078144390
Other	A1	Platform control box	1	307P218040	307P218040
Other	A2	Ground control box	1	307P218030	307P218030

C

- Machine layout

Color	Marking	Description	Quantity	HA12IP (HA33JE)	HA15IP (HA43JE)
Other	A3	Identification plate	1	307P218070	307P218070
Other	A4	Machine name logo	1	307P218260	307P218250
Other	A5	Small format HAULOTTE® logo	1	307P217080	307P217080
Other	A7	Read the operation manual	1	3078143680	3078143680
Other	A8	Hydraulic oil	1	3078143520	3078143520
Other	A8	Biodegradable oil	1	3078148890	3078148890
Other	A9	Upper and lower oil level	1	3078143590	3078143590
Other	A11	Front green drive direction arrow	1	3078137440	3078137440
Other	A12	Rear red drive direction arrow	1	3078137430	3078137430
Other	A15	Harness anchor point location	2	307P216290	307P216290
Other	A16	Yellow and black adhesive tape	1	2421808660	2421808660
Other	A28	Risks of electrocution	1	For AS standard only : 307P226440	For AS standard only : 307P226440
Other	A30	Machine tie down points	2	3078147930	3078147930
Other	A32	Vertical machine name logo	1	3078148310	3078152050
Other	A81	Battery	1	307P226540	307P226540

Label descriptions-Standards CE and AS

Color	Marking	Description	Quantity	HA16PE
Red	R1	Height of the floor and load	2	3078143700
Red	R2	Travel direction	1	3078145070
Red	R3	Risk of crushed hands	2	3078143620
Red	R4	Risk of body crushing	2	3078143630
Red	R5	Danger of electrocution	1	3078143490
Red	R6	Do not interchange	1	3078145180
Red	R7	Do not park in the work area	1	3078143550
Red	R8	Close the sliding mid-rail	1	3078153510
Red	R9	Wheel load	4	3078151600
Red	R14	Fuel filling-up	1	For AS standard only : 3078144510
Red	R15	Harness use	1	For AS standard only : 3078144520
Red	R16	Load strength on each slings	4	For AS standard only : 3078144490
Red	R17	Do not travel down slopes at high speed	1	CE standard : 3078143970 AS standard : 3078144360
Red	R21	Protective clothing required	1	3078143610

C


- Machine layout

Color	Marking	Description	Quantity	HA16PE
Orange	O1	Operation instructions	1	In french CE standard : 3078143420 In english Standards CE and AS : 3078144560 In german CE standard : 3078143440 In spanish CE standard : 3078143430 In italian CE standard : 3078143460 In danish CE standard : 3078144940 In portuguese CE standard : 3078145830 In finish CE standard : 3078145540 In swedish CE standard : 3078145940 In dutch CE standard : 3078143470
				In english Standards CE and AS : 307P227220
				3078143570
				3078143530
				3078143640
				3078143600
				3078144650
				3078143540 AS standard : 3078144570
				3078143510
				3078143560
				For AS standard only : 3078144390
				307P217990
				3078143040
				307P218070
				307P218270
Other	A1	Platform control box	1	307P217770
	A2	Ground control box	1	3078143680
	A3	Identification plate	1	3078143520
	A4	Machine name logo	1	
Other	A5	Small format HAULOTTE® logo	3	
Other	A7	Read the operation manual	1	
Other	A8	Hydraulic oil	1	


C - Machine layout

Color	Marking	Description	Quantity	HA16PE
Other	A8	Biodegradable oil	1	3078148890
Other	A9	Upper and lower oil level	1	3078143590
Other	A10	Noise emission level	1	For CE standard only : 3078148700
Other	A11	Front green drive direction arrow	1	3078137440
Other	A12	Rear red drive direction arrow	1	3078137430
Other	A15	Harness anchor point location	2	307P216290
Other	A16	Yellow and black adhesive tape	1	2421808660
Other	A28	Risks of electrocution	1	For AS standard only : 307P226440
Other	A30	Machine tie down points	2	3078147930
Other	A32	Vertical machine name logo	1	3078148580

HA12CJ / HA12CJ+ (HA33CJ / HA33CJ+)-Locations - Standards CE and AS



C - Machine layout



Label descriptions-Standards CE and AS

Color	Marking	Description	Quantity	HA12CJ (HA33CJ)	HA12CJ+ (HA33CJ+)
Red	R1	Height of the floor and load	2	307P228420	307P228510
Red	R3	Risk of crushed hands	4	307P219350	307P219350
Red	R4	Risk of body crushing	2	3078143630	3078143630
Red	R5	Danger of electrocution	1	3078143490	3078143490
Red	R6	Do not interchange	4	3078145180	3078145180
Red	R7	Do not park in the work area	2	3078143550	3078143550
Red	R8	Close the sliding mid-rail	1	3078153510	3078153510
Red	R9	Wheel load	4	307P228410	307P228410
Red	R15	Wearing of a safety harness is essential	1	For AS standard only : 3078144520	For AS standard only : 3078144520
Red	R16	Load strength on each slings	4	For AS standard only : 307P229500	For AS standard only : 307P229500
Red	R17	Do not travel down slopes at high speed	2	CE standard : 3078143970 AS standard : 3078144360	CE standard : 3078143970 AS standard : 3078144360

C - Machine layout

Color	Marking	Description	Quantity	HA12CJ (HA33CJ)	HA12CJ+ (HA33CJ+)
Red	R20	Travel direction	1	For AS standard only : 3078145230	For AS standard only : 3078145230
Red	R21	Protective clothing required	1	3078143610	3078143610
Red	R36	Manual emergency maintenance procedure	1	307P228460	307P228460
Red	R52	Driving with the battery compartment open is strictly forbidden	1	For AS standard only : 3078148240	For AS standard only : 3078148240
Red	R53	Basket in compliance with EN 280 standard	1	For AS standard only : 3078144540	For AS standard only : 3078144540
Red	R54	Emergency operation	1	For AS standard only : 307P229510	For AS standard only : 307P229510
Red	R58	Oil viscosity	1	307P229300	307P229300
Orange	O1	Operation instructions	1	In french CE standard : 3078143420	In french CE standard : 3078143420
				In english Standards CE and AS : 3078144560	In english Standards CE and AS : 3078144560
				In german CE standard : 3078143440	In german CE standard : 3078143440
				In spanish CE standard : 3078143430	In spanish CE standard : 3078143430
				In italian CE standard : 3078143460	In italian CE standard : 3078143460
				In danish CE standard : 3078144940	In danish CE standard : 3078144940
				In portuguese CE standard : 3078145830	In portuguese CE standard : 3078145830
				In finish CE standard : 3078145540	In finish CE standard : 3078145540
				In swedish CE standard : 3078145940	In swedish CE standard : 3078145940
				In dutch CE standard : 3078143470	In dutch CE standard : 3078143470
				In english Standards CE and AS : 307P227220	In english Standards CE and AS : 307P227220
Yellow	J1	Greasing the turntable rotation gear	1	3078143570	3078143570
Yellow	J2	Remove the blocking pin before rotating	1	307P228440	307P228440
Yellow	J3	Do not place your foot on the cover	4	3078143640	3078143640


C

- Machine layout

Color	Marking	Description	Quantity	HA12CJ (HA33CJ)	HA12CJ+ (HA33CJ+)
Yellow	J4	Do not use the machine as a welding earth	4	3078143600	3078143600
Yellow	J6	Verification of tilt operation	1	3078144650	3078144650
Yellow	J10	Socket 110 V	1	For AS standard only : 3078147580	For AS standard only : 3078147580
Yellow	J10	Socket 220 V	1	3078143540	3078143540
Yellow	J10	Socket 240 V	1	For AS standard only : 3078144570	For AS standard only : 3078144570
Yellow	J13	Battery verification	1	3078143510	3078143510
Yellow	J14	Using the machine during battery charging is forbidden	1	3078143560	3078143560
Yellow	J33	Battery compartment locking	2	307P228450	307P228450
Yellow	J34	Lifting forbidden	2	307P228780	307P228780
Other	A1	Platform control box	1	307P227720	307P227720
Other	A2	Ground control box	1	307P227740	307P227740
Other	A3	Identification plate	1	307P218070	307P218070
Other	A5	Small format HAULOTTE® logo	2	307P217080	307P217080
Other	A7	Read the operation manual	1	3078143680	3078143680
Other	A8	Winter grade hydraulic oil	1	307P222390	307P222390
Other	A8	Biodegradable oil	1	3078148890	3078148890
Other	A8	Hydraulic oil for hot countries	1	307P223730	307P223730
Other	A11	Front green drive direction arrow	1	3078137440	3078137440
Other	A12	Rear red drive direction arrow	1	3078137430	3078137430
Other	A15	Harness anchor point location	1	307P216290	307P216290
Other	A16	Yellow and black adhesive tape	2	2421808660	2421808660
Other	A28	Risks of electrocution	1	For AS standard only : 307P226440	For AS standard only : 307P226440
Other	A32	Machine name logo	2	307P227900	307P227880
Other	A81	Battery unit	1	CE standard : 307P228000 AS standard : 307P229480	CE standard : 307P228000 AS standard : 307P229480
Other	A82	Plastic protection	2	307P228790	307P228790
Other	A83	Manual emergency maintenance procedure	1	307P228460	307P228460

C - Machine layout

HA12IP - HA15IP (HA33JE - HA43JE) - Locations - ANSI - CSA




C - Machine layout

Label descriptions-ANSI - CSA


Color	Marking	Description	Quantity	HA12IP (HA33JE)	HA15IP (HA43JE)
Red	R1	Height of the floor and load	2	3078148120	3078148120
Red	R2	Travel direction	1	3078147300	3078147300
Red	R3	Risk of crushed hands	2	3078147240	3078147240
Red	R4	Risk of body crushing	2	3078147260	3078147260
Red	R5	Danger of electrocution	1	3078147100	3078147100
Red	R6	Do not interchange	1	3078147320	3078147320
Red	R7	Do not park in the work area	1	3078147170	3078147170
Red	R8	Close the sliding mid-rail	1	3078153630	3078153630
Red	R9	Wheel load	4	307P216650	307P215110
Red	R17	Do not travel down slopes at high speed	1	3078148140	3078148140
Red	R21	Protective clothing required	1	3078147350	3078147350
Red	R50	Socket - 110V	1	3078147580	3078147580
Red	R58	Oil viscosity	1	307P229300	307P229300
Orange	O1	Operation instructions	1	3078147050	3078147050
Orange	O3	Risks of explosion	1	3078148030	3078148030
Yellow	J1	Greasing the turntable rotation gear	1	3078147190	3078147190
Yellow	J2	Remove the blocking pin before rotating	1	3078147700	3078147700
Yellow	J3	Do not place your foot on the cover	2	3078147270	3078147270
Yellow	J4	Do not use the machine as a welding earth	1	3078147220	3078147220
Yellow	J6	Verification of tilt operation	1	3078147090	3078147090
Yellow	J10	Socket	1	3078147580	3078147580
Yellow	J13	Battery verification	1	3078147330	3078147330
Yellow	J14	Using the machine during battery charging is forbidden	1	3078147370	3078147370
Other	A1	Platform control box	1	307P218040	307P218040
Other	A2	Ground control box	1	307P218030	307P218030
Other	A3	Identification plate	1	307P218170	307P218170
Other	A4	Machine name logo	1	3078148150	3078153610
Other	A5	Small format HAULOTTE® logo	1	307P217080	307P217080
Other	A7	Read the operation manual	1	3078147290	3078147290
Other	A8	Hydraulic oil	1	3078147140	3078147140
Other	A8	Biodegradable oil	1	3078148920	3078148920
Other	A9	Upper and lower oil level	1	3078147210	3078147210
Other	A11	Front green drive direction arrow	1	3078147980	3078147980
Other	A12	Rear red drive direction arrow	1	3078147970	3078147970
Other	A15	Harness anchor point location	1	3078147950	3078147950
Other	A16	Yellow and black adhesive tape	1	2421808660	2421808660
Other	A22	Voltage table	1	3078147890	3078147890
Other	A27	Permissible load	1	307P200080	307P200080
Other	A29	Summary safety instructions	1	3078150170	3078150170
Other	A30	Machine tie down points	2	3078147930	3078147930
Other	A32	Vertical machine name logo	1	3078148320	3078153620
Other	A81	Battery	1	307P226540	307P226540

C - Machine layout

HA12CJ / HA12CJ+ (HA33CJ / HA33CJ+)-Locations - ANSI - CSA



C - Machine layout



C - Machine layout

Label descriptions - ANSI - CSA

Color	Marking	Description	Quantity	HA12CJ (HA33CJ)	HA12CJ+ (HA33CJ+)
Red	R1	Height of the floor and load	2	307P228670	307P228680
Red	R3	Risk of crushed hands	4	307P228830	307P228830
Red	R4	Risk of body crushing	2	3078147260	3078147260
Red	R5	Danger of electrocution	1	3078147100	3078147100
Red	R6	Do not interchange	4	3078147320	3078147320
Red	R7	Do not park in the work area	2	3078147170	3078147170
Red	R9	Wheel load	4	307P228640	307P228640
Red	R16	Load strength on each slings	4	307P229500	307P229500
Red	R17	Do not travel down slopes at high speed	2	3078148140	3078148140
Red	R21	Protective clothing required	1	3078147350	3078147350
Red	R58	Oil viscosity	1	307P229300	307P229300
Orange	O1	Operation instructions	1	3078147050	3078147050
Orange	O3	Risks of explosion	2	3078148030	3078148030
Yellow	J1	Greasing the turntable rotation gear	1	3078147190	3078147190
Yellow	J2	Remove the blocking pin before rotating	1	307P228650	307P228650
Yellow	J3	Do not place your foot on the cover	4	3078147270	3078147270
Yellow	J4	Do not use the machine as a welding earth	4	3078147220	3078147220
Yellow	J6	Verification of tilt operation	1	3078147090	3078147090
Yellow	J10	Socket 110 V	1	3078147580	3078147580
Yellow	J13	Battery verification	1	3078147330	3078147330
Yellow	J14	Using the machine during battery charging is forbidden	1	3078147370	3078147370
Yellow	J33	Battery compartment locking	2	307P228660	307P228660
Yellow	J34	Lifting forbidden	2	307P228810	307P228810
Other	A1	Platform control box	1	307P227720	307P227720
Other	A2	Ground control box	1	307P227740	307P227740
Other	A3	Identification plate	1	307P218170	307P218170
Other	A5	Small format HAULOTTE® logo	2	307P217080	307P217080
Other	A7	Read the operation manual	1	3078147290	3078147290
Other	A8	Winter grade hydraulic oil	1	307P222400	307P222400
Other	A8	Biodegradable oil	1	3078148920	3078148920
Other	A8	Hydraulic oil for hot countries	1	307P225760	307P225760
Other	A11	Front green drive direction arrow	1	3078147980	3078147980
Other	A12	Rear red drive direction arrow	1	3078147970	3078147970
Other	A15	Harness anchor point location	1	3078147950	3078147950
Other	A16	Yellow and black adhesive tape	2	2421808660	2421808660
Other	A22	Voltage table	1	3078147890	3078147890
Other	A29	Safety precautions	1	3078150170	3078150170
Other	A32	Machine name logo	2	307P228490	307P228470
Other	A81	Battery unit	1	307P228000	307P228000
Other	A82	Plastic protection	2	307P228790	307P228790
Other	A83	Manual emergency maintenance procedure	1	307P228460	307P228460


C - Machine layout

5 - Control boxes

N.B.:-THE FUNCTIONS ARE DESCRIBED FOR THE ENTIRE RANGE. REFER TO THE MACHINE MODEL TO IDENTIFY THE CONTROLS AND FUNCTIONS INDICATORS.

5.1 - GROUND CONTROL BOX

HA12IP (HA33JE) - HA15IP (HA43JE) - General view



C - Machine layout

HA12IP (HA33JE) - HA15IP (HA43JE) - Controls and indicators

Marking	Description	Function
8	Jib lifting / lowering selector	Move upwards : Jib lifting Move downwards : Jib lowering
9	Boom telescoping selector	Move to the left : To telescope out Move to the right : To telescope in
10	Boom raising selector	Move upwards : Boom raising Move downwards : Boom lowering
12	Arm lifting selector	Move upwards : Arm lifting Move downwards : Boom lowering
13	Platform levelling or transport position selector	Move to the right : Platform leveling lowered or placed in transport position Move to the left : Platform compensation lifted or placed in operating position
14	Turntable rotation selector	Move to the left : Counter clockwise (CCW) rotation Move to the right : Clockwise rotation
15	Emergency stop button	Pulled out (activated) : Ground control box energized Pushed down (deactivated) : De-energizes control system
24	Beacon light on/off (Option)	Move to the right : Beacon light on Move to the left : Beacon light off
72	Control box energizing key selector	Left : Platform control box energized Center : De-energizes control system Rotate to right and hold : Ground control box energized
91	Hour meter-Battery charge indicator	Total machine running hours - Battery charger status
93	Battery charging indicator	Battery charge level status during battery charging
230	Control box energizing key selector / 'Enable Switch' selector ¹	Left : Platform control box energized Center : De-energizes control system Rotate to right and hold : Ground control box energized movement validationRelease : Movement stopped

1. For machines fitted with

Photo HA12IP (HA33JE) - HA15IP (HA43JE)




C - Machine layout

Battery charging indicator



HA16PE - General view



C - Machine layout

HA16PE - Controls and indicators

Marking	Description	Function
2	Engine oil pressure light	Low engine oil pressure ¹
3	Engine temperature indicator	High engine oil temperature ¹
4	Battery charge indicator	Low battery charge ¹
5	Air filter clogging indicator	Clogged air filter ¹
8	Jib lifting / lowering selector	Move upwards : Jib lifting Move downwards : Jib lowering
9	Boom telescoping selector	Move to the left : To telescope out Move to the right : To telescope in
10	Boom raising selector	Move upwards : Boom raising Move downwards : Boom lowering
12	Arm lifting selector	Move upwards : Arm lifting Move downwards : Boom lowering
14	Turntable rotation selector	Move to the left : Counter clockwise (CCW) rotation Move to the right : Clockwise rotation
15	Emergency stop button	Pulled out (activated) : Ground control box energized Pushed down (deactivated) : De-energizes control system
20	Hour meter	Total machine running hours
21	Engine acceleration selector	Move to the right : Engine speed increases Move to the left : Engine idle speed
22	Engine start-up selector	Starting the engine
24	Beacon light on/off	Move to the right : Beacon light on Move to the left : Beacon light off
72	Control box energizing key selector	Left : Platform control box energized Center : De-energizes control system Right : Ground control box energized
89	Bi-energy selector	Move to the right : Electric power supply Move to the left : Petrol or Optional diesel power supply
90	Battery charge indicator	Battery charger status
93	Battery charging indicator	Battery charge level status during battery charging

1. Perform the required maintenance (see the machine maintenance book)

C - Machine layout

Photo HA16PE




Battery charging indicator



C - Machine layout

HA12CJ (HA33CJ) - HA12CJ+ (HA33CJ+) - General view



C

- Machine layout

HA12CJ (HA33CJ) - HA12CJ+ (HA33CJ+) - Controls and indicators

Marking	Description	Function
6	Platform overload indicator	Platform overload
8	Jib lifting / lowering selector	Move upwards : Jib lifting Move downwards : Jib lowering
9	Boom telescoping selector	Move to the left : To telescope out Move to the right : To telescope in
10	Boom raising selector	Move upwards : Boom raising Move downwards : Boom lowering
12	Arm lifting selector	Move upwards : Arm lifting Move downwards : Boom lowering
13	Platform levelling or transport position selector	Move to the left : Platform compensation lifted or placed in operating position Move to the right : Platform leveling lowered or placed in transport position
14	Turntable rotation selector	Move to the left : Counter clockwise (CCW) rotation Move to the right : Clockwise rotation
15	Emergency stop button	Pulled out (activated) : Ground control box energized Pushed down (deactivated) : De-energizes control system
20	Hour meter	Total machine running hours
72	Control box energizing key selector	Left : Platform control box energized Center : De-energizes control system Right : Ground control box energized
74	Jib rotation selector ¹	Move to the left : Counter clockwise (CCW) rotation Move to the right : Clockwise rotation
228	'Enable Switch' selector / Back-up unit selector ²	Move upwards : Movement validation Move downwards : Back-up unit activated Movement validation
232	Battery discharge indicator	

1. For HA12CJ+ (HA33CJ+) only

2. For machines fitted with

C - Machine layout

Photo HA12CJ (HA33CJ) - HA12CJ+ (HA33CJ+)




Battery charging indicator



C - Machine layout

5.2 - PLATFORM CONTROL BOX

HA15IP (HA43JE) - HA12IP (HA33JE) - General view



C - Machine layout

HA12IP (HA33JE)-HA15IP (HA43JE) - Controls and indicators


Marking	Description	Function
30	Platform overload indicator	Platform overload
31	Power ON indicator	On : Machine switched on Off : Machine switched off
46	Emergency stop button	Pulled out (activated) : Platform control box power supply energized Pushed down (deactivated) : De-energizes control system
52	Movement joystick	Move forward : • Forward drive • Jib lifting • Counter clockwise (CCW) platform rotation • Platform levelling raising • Arm lifting • Boom raising • Boom telescope in • Counter clockwise (CCW) turntable rotation
		Move backward : • Reverse drive • Jib lowering • Clockwise platform rotation • Platform levelling lowering • Boom lowering • Boom lowering • Boom telescope out • Clockwise turntable rotation
	Front axle steering selector	Press right side of button : Right-hand steering Press left side of button : Left-hand steering
57	Low-speed drive selector switch with indicator light	Pressed down (activated and LED on) : Low-speed drive selection (for short distance and final approach)
59	High-speed drive selector switch with indicator light	Pressed down (activated and LED on) : High-speed drive selection (for long distance)
62	Horn selector switch	Pressed down (activated) : Horn
63	Jib selector switch with indicator light	Pressed down (activated and LED on) : Jib selection
64	Platform rotation selector switch with indicator light	Pressed down (activated and LED on) : Platform rotation selection
65	Platform levelling selector switch with indicator light	Pressed down (activated and LED on) : Platform compensation selection
66	Arm elevation selector switch with indicator light	Pressed down (activated and LED on) : Arm lifting selection
67	Boom lifting selector switch with indicator light	Pressed down (activated and LED on) : Boom lifting selection
68	Boom telescope selector switch with indicator light	Pressed down (activated and LED on) : Boom telescope selection
69	Turntable rotation selector switch with indicator light	Pressed down (activated and LED on) : Turntable rotation selection

C - Machine layout

Photo HA12IP (HA33JE) - HA15IP (HA43JE)



HA16PE - General view



C - Machine layout

HA16PE - Controls and indicators

Marking	Description	Function
26	Fault indicator	Operation malfunction ¹ Machine on excessive slope
30	Platform overload indicator	Platform overload
31	Power ON indicator	On : Machine switched on Off : Machine switched off
35	Differential lock selector	Press in and hold (activated) : Maximum drive torque (on difficult or sloping ground) Release (deactivated) : Standard torque
37	Jib lifting / lowering selector	Move upwards : Jib lifting Move downwards : Jib lowering
38	Platform rotation selector	Move to the right : Counter clockwise (CCW) rotation Move to the left : Clockwise rotation
40	Platform leveling selector	Move upwards : Platform elevation Move downwards : Platform lowers
41	Not used	
42	Engine start-up selector	Starting the engine
43	Horn selector	Horn
46	Emergency stop button	Pulled out (activated) : Ground control box energized Pushed down (deactivated) : De-energizes control system
49	Turntable rotation joystick	Move to the right : Counter clockwise (CCW) rotation Move to the left : Clockwise rotation
	Boom lift joystick	Move upwards : Boom raising Move downwards : Boom lowering
50	Arm lifting/lowering joystick	Move forward : Arm lifting Move backward : Boom lowering
54	Boom telescoping selector	Move to the right : To telescope in Move to the left : To telescope out
		High-speed driving
71	Drive speed selector	Medium-speed drive (difficult ground, slope)
		Low-speed driving
86	Drive joystick	Move forward : Forward drive Move backward : Reverse drive
	Rear axle steering selector	Press right side of button : Right-hand steering Press left side of button : Left-hand steering
87	Front axle steering selector	Move to the right : Right-hand steering Move to the left : Left-hand steering
88	Bi-energy selector	Move to the right : Electric power supply Move to the left : Petrol or Optional diesel power supply


1. Perform the required maintenance (see the machine maintenance book)

C - Machine layout

Photo HA16PE





General view HA12CJ (HA33CJ) - HA12CJ+ (HA33CJ+)



Controls and indicators HA12CJ (HA33CJ) - HA12CJ+ (HA33CJ+)

Marking	Description	Function
27	Tilt indicator	Machine on excessive slope
30	Platform overload indicator	Platform overload
31	Power ON indicator / Fault	On : Machine switched on Flashing : Machine operating fault Off : Machine switched off
33	Drive joystick	Move forward : Forward drive Move backward : Reverse drive
	Front axle steering selector	Press right side of button : Right-hand steering Press left side of button : Left-hand steering
37	Jib lifting / lowering selector	Move upwards : Jib lifting Move downwards : Jib lowering
38	Platform rotation selector	Move to the right : Counter clockwise (CCW) rotation Move to the left : Clockwise rotation

C - Machine layout

Marking	Description	Function
40	Platform leveling selector	Move upwards : Platform elevation Move downwards : Platform lowers
41	Back-up unit selector ¹	Press in and hold : Back-up unit activated Release : Back-up unit deactivated
43	Horn selector	Horn
45	Drive speed selector	 High-speed driving  Low-speed driving
46	Emergency stop button	Pulled out (activated) : Ground control box energized Pushed down (deactivated) : De-energizes control system
49	Turntable rotation joystick	Move to the right : Counter clockwise (CCW) rotation Move to the left : Clockwise rotation
	Boom lift joystick	Move upwards : Boom raising Move downwards : Boom lowering
83	Jib rotation selector ²	Move to the left : Clockwise rotation Move to the right : Counter clockwise (CCW) rotation
242	Speed reduction button for movements in zone 	Press the + button down : Increases the operating speed of functions controlled by the toggle switches.
243	Speed increase button for movements in zone 	Press the - button down : Decreases the operating speed of functions controlled by the toggle switches.
244	Speed status indicator for movements in zone 	The light bar position on the scale signifies where the speed selector is position within the maximum and minimum scale.
245	Battery discharge indicator	The position of the light bar indicates the proportion of charge left in the batteries with the RH end of the scale being maximum charge and the LH end being low charge.
246	Boom telescoping selector	Move to the left : To telescope out Move to the right : To telescope in
247	Arm lifting selector	Move upwards : Arm lifting Move downwards : Boom lowering

1. For machines fitted with

2. For HA12CJ+ (HA33CJ+) only

C - Machine layout


Photo HA12CJ (HA33CJ) - HA12CJ+ (HA33CJ+)



C - Machine layout

5.3 - VARIOUS COMPONENTS


HA12IP (HA33JE)-HA15IP (HA43JE)



HA12IP (HA33JE)-HA15IP (HA43JE)

Marking	Description	Function
1	Battery charger socket	Connection point for onboard battery charger
SQ1	Tilt sensor switch	Senses ground slope on which machine is operating
SB1	Battery isolation switch	Machine shutdown

HA12CJ (HA33CJ)-HA12CJ+ (HA33CJ+)



HA12CJ (HA33CJ)-HA12CJ+ (HA33CJ+)

Marking	Description	Function
SQ1	Tilt sensor switch	Senses ground slope on which machine is operating
S1	Battery isolation switch	Machine shutdown

D - Operating principle

1 - Description

For : HA12IP (HA33JE) - HA15IP (HA43JE) - HA12CJ (HA33CJ) - HA12CJ+ (HA33CJ+)

Hydraulic energy to perform machine movements is provided by an electric motor driven hydraulic pump. The operating speed of the pump is governed by a speed regulator.

For : HA16PE

Hydraulic energy for machine movement is provided by a pump unit.

The power supplied to the electric motor(s) is generated by batteries.

To protect the user and the machine, safety systems prevent the operation of the machine beyond its capacities.  Section G Technical characteristics

These security systems if activated, immobilize the machine and neutralize the movements.



Poor knowledge of the characteristics and operation of the machine can lead the operator to think that a normal safety operation is a malfunction.

2 - Safety devices

2.1 - ACTIVATION OF CONTROLS

The controls must be validated by a 'Enable Switch' system to activate the different movements.

The 'Enable Switch' system depends on the machine configuration and will consist of one of the following :

- Joystick handle.
- Pedal.
- Validation button.

2.2 - DRIVE SPEED

All driving speeds are authorised when the machine is stowed.

For : HA12IP (HA33JE) - HA15IP (HA43JE)

The electronic variable speed unit controls movement and driving speed.

It receives information from the control joystick concerning the movements to be performed. It also manages the safety systems status.

For : HA12CJ (HA33CJ) - HA12CJ+ (HA33CJ+)

The electronic variable speed unit controls movement and driving speed.

It receives data from the joystick and buttons via the machine calculator. It also manages the operation and state of the machine safety systems.

The variable speed unit regulates the speed.



D - Operating principle

This device has the following functions :

- Prevention of engine racing.
- Triggering of reverse braking if necessary.

2.3 - ELECTRONIC VARIABLE SPEED DRIVE

For HA12IP (HA33JE) - HA15IP (HA43JE) - HA16PE :

The machines are equipped with an electronic speed regulator configured for each function.

For HA12CJ (HA33CJ) - HA12CJ+ (HA33CJ+) :

The machines are fitted with an electronic variable speed drive which manages the power supplied to the drive motors and hydraulic pump motor. Power to the motors is controlled by the machine calculator.



The speed regulators are configured for each individual machine. Do not interchange the speed controllers/regulators between machines even if they are the same model..

2.4 - ON-BOARD ELECTRONICS

For HA12CJ (HA33CJ) - HA12CJ+ (HA33CJ+) - HA16PE

The machines are equipped with one/several specific calculator(s) configured for the machine's functionalities.



Do not interchange the calculator between machines.

2.5 - DETECTION OF INTERNAL FAULT

For HA12CJ (HA33CJ) - HA12CJ+ (HA33CJ+) - HA16PE :

N.B.-:THE PRESENCE OF THIS DEVICE DEPENDS ON THE MACHINE CONFIGURATION.

The fault or power indicator flashes to show an internal malfunction.

The machine switches to downgraded mode.

Certain movements can be limited or forbidden to preserve the operator's safety.



2.6 - AUTOMATIC ENGINE CUT-OUT

For HA16PE only

The engine automatically cuts out in the following conditions (Please see machine configuration) :

- The alternator is not functioning.
- Engine temperature is too high.
- Oil pressure is too low.
- A machine malfunction is detected.

2.7 - LOAD LIMITING IN THE PLATFORM (IF FITTED)

If the platform load exceeds the maximum authorized load, no movement is possible from the platform control box.

The platform overload indicator and the buzzer warn the operator that the overload condition exists..

To return the machine to normal operation remove some weight from the platform.



D - Operating principle

2.8 - CHASSIS TILT

If the machine is standing on a slope exceeding the authorized slope and if the machine is not in the transport position, the fault indicator and buzzer warn the operator.

Driving and certain movements are cut off (If the machine is unfolded).

To restore the drive function, only movements allowing the machine to be stowed are permitted :

For HA12IP (HA33JE) - HA15IP (HA43JE) - HA16PE :

- Boom lowering to return to a horizontal position.
- Lowering the arm.
- Lowering the jib until it is below horizontal position (According to the machine configuration).

For HA12CJ (HA33CJ) - HA12CJ+ (HA33CJ+) :

- Boom lowering to return to a low position.
- Lowering the arm.
- Lowering the jib until it is below horizontal position (According to the machine configuration).

N.B.:-LOWERING IS ALLOWED IF THE TELESCOPE IS FULLY RETRACTED.

2.9 - BATTERY DISCHARGE INDICATOR-HOUR METER

Display by % charge (The tenth lit bar graph segment corresponds to 100 %) :

- 100 % charge : Battery correctly charged.
- 20 % charge : The batteries must be recharged. The movement ascent is stopped.

2.9.1 - Hour meter

For : HA16PE :

It totals up :

- Machine operating hours (the egg timer flashes).
- Electropump operating time (bi-energy mode).

For : HA12IP (HA33JE) - HA15IP (HA43JE) :

It displays :

- P = Pump operating time.
- T = Operating time in drive.
- Length of time the machine is energized (even if not in use).

For : HA12CJ (HA33CJ) - HA12CJ+ (HA33CJ+) :

It totals up :

- The machine operating hours (Movements and travel).

D

- Operating principle

2.9.2 - Automatic reset

The automatic restart is coming up at a certain voltage level.

The automatic restart doesn't mean that the battery is fully charged.

Only the indicator of the charger gives the real state of the batteries charge.

2.10 - ON-BOARD CHARGER

The on-board charger is used to charge the semi-traction or traction batteries.

the maximum amperage is 30 A for the 100 - 110 V networks and 16 A for the 220 - 240 V networks.

Battery charging starts as soon as external power supply is connected (No movement is allowed during the charging process.).

2.10.1 - Black charger - Network 110 V - USA

Black charger



The (93) indicator indicates charge status :

- Green LED : Battery 100 % charged.
- Yellow LED : Battery 80 % charged.
- Red LED : Battery in initial charging phase.

If a fault occurs, the indicator flashes in different colours, depending on the type of fault (See machine maintenance book). The audible beep sounds.

D

- Operating principle

2.10.2 - Metal charger - Network 230 V

Metal charger



The (93) indicator indicates charge status :

- Green LED : Battery 100 % charged (Flashing LED in the equalization phase).
- Yellow LED : Battery 80 % charged.
- Red LED : Battery in initial charging phase.

In case of a fault, the indicator flashes red to indicate an excessive charging time, short-circuit battery components, errors in the temperature reading, or an excessive ambient temperature.

D

- Operating principle

E - Driving

1 - Recommendations

The manager of the company responsible for the commissioning of the machine must ensure that the machine is fit for the work it is to perform. i.e. that the machine is suitable to carry out the work in complete safety in compliance with this Operator Manual. All managers who are responsible for persons operating the machine, must be familiar with the regulations currently applicable in the country of use and ensure that they are adhered to.



Before using the machine, read the previous chapters in this manual. Ensure that you have understood the following points :

- Safety precautions.
- Operator's responsibilities.
- Presentation and the operating principle of the machine.

2 - Checks before use

Each day and before the beginning of a new work period and on each change of operator, the machine must be subjected to a visual inspection and a complete functional test.

Any repairs required must be performed before the machine is used, its correct operation depends on it.



Find all the function indicators and controls in  Section C 5 - Control boxes

2.1 - VISUAL INSPECTIONS

2.1.1 - General mechanical functions

For all the following checks, ensure that the machine is switched off.


Check the following points :

- The presence of the identification plate, labels and operator manual :
 - Their state of cleanliness and visibility.
 - Clean or replace if necessary.
- Visual state of the machine :
 - Absence of leaks (battery acid, hydraulic oil, etc.). Absence of foreign objects on all surfaces. Call the staff in charge of the maintenance if necessary.
 - No missing or loose parts (bolts, nuts, connectors, cables, etc.). Refer to the "tightening torques" table quoted in the Maintenance Book.

E - Driving

- Absence of cracks, broken parts, damaged paint. No deformations or other anomalies on the structure's parts.

Example



- Cylinders' state :
 - No leaks. Refer to the Maintenance book.
 - No rust and abrasions on the cylinder rod.
 - Absence of foreign objects on all surfaces.
- Steering system's state : wheels, reducers, brakes and tires :
 - No cracks, distortions, damaged paint or other faults
 - No missing or loose bolts. Refer to the "tightening torques" table quoted in the Maintenance Book.
 - Condition of the tyres (cuts, excessive wear, etc.).
- Status of the control boxes :
 - No damage.
 - Back to neutral for all joysticks, selectors, etc..
 - Presence and readability of the control box labels.
- Movement, safety limit switches :
 - No damage.
 - No missing or loose bolts. Refer to the "tightening torques" table quoted in the Maintenance Book.
 - Absence of foreign objects on all surfaces.
- The state and connection of the electric wires and cables :
 - No damage, wear marks or other faults.
 - No contact between connectors.
- State of the hydraulic unit and pump :
 - No leaks.
 - No missing or loose parts (bolts, nuts, connectors, cables, etc.).
- Hydraulic oil filter. Refer to the Maintenance book.

E - Driving

- State of the structure's parts : Arm, boom, jib, cage (or platform) :
 - No cracks, damaged paint.
 - No distortion in metal components or visible damage.
 - No foreign objects at the ends of the booms, between arms and link parts.
 - Presence and check the original position of the platform control box sliding bar.
- State of the rotation systems : Turntable rotation, Turntable rotation selector in platform, Jib orientation (For machines fitted with).
 - No excessive clearance : Refer to the Maintenance book.
 - No missing or loose bolts.
 - Absence of foreign objects on all surfaces.
 - Greasing the turntable rotation gear Turntable and Platform.
- State of the tanks :
 - No leaks.
 - No missing or loose parts (bolts, nuts, connectors, cables, etc.). Top up the oil level, if necessary (Machine in transport position).

2.1.2 - Environment

 Section A - Safety precautions.

Check the following points :

- Wind speed ( Section G 1- Main characteristics).
- The permissible ground pressure and loading on the machine supporting surface ( Section G 1- Main characteristics).
- The maximum permissible load in the platform ( Section G 1- Main characteristics).
- The maximum permissible lateral force allowed at the platform ( Section G 1- Main characteristics).

2.2 - FUNCTIONAL TESTS

2.2.1 - Safety features

Features to be tested :

- Operation of the upper and lower emergency stop buttons.
- Operation of the tilt sensor.
- Visual and audible alarms.
- Platform load management system (Where fitted).
- Movement, safety limit switches.

For functional test procedures refer to ( Section E 3.1- Test procedure).

E - Driving

2.2.2 - Ground control box controls (emergency station)

Refer to the corresponding operations to test the controls in the order mentioned ( Section E 3.2- Operation from ground position).

on HA12IP (HA33JE) and HA15IP (HA43JE) only

Step	Control
1	Energizes control system 72, 230
2	Movements : • Jib lifting/lowering 8 • Boom telescope out/in 9 • Lifting / lowering of boom 10 • Lifting/lowering of arm 12 • Platform leveling 13 • Turntable rotation 14
3	Beacon light on/off 24
4	Control box energizing key selector 72, 230

on HA12CJ (HA33CJ) and HA12CJ+ (HA33CJ+) only

Step	Control
1	Energizes control system 72
2	Movements : • Jib lifting/lowering 8 • Boom telescope out/in 9 • Lifting / lowering of boom 10 • Lifting/lowering of arm 12 • Platform leveling 13 • Turntable rotation 14 • Jib rotation 74
3	Control box energizing key selector 72

For HA16PE only

Step	Control
1	Engine start-up selector 22
2	Engine acceleration selector 21
3	Movements : • Jib lifting/lowering 8 • Boom telescope out/in 9 • Lifting / lowering of boom 10 • Lifting/lowering of arm 12 • Turntable rotation 14
4	Beacon light on/off 24
5	Control box energizing key selector 72

E - Driving

2.2.3 - Platform control box controls (driving station)

Refer to the corresponding operations to test the controls in the order mentioned ( Section E 3.3- Operations from the platform).

For HA12IP (HA33JE) - HA15IP (HA43JE)

Step	Control
1	Energizes control system 72
2	Steering switch (52) and movement joystick (52)
3	Movements : • Jib elevation/lowering (63) and movement joystick 52 • Platform rotation (64) and movement joystick 52 • Platform compensation (65) and movement joystick 52 • arm lifting/lowering (66) and movement joystick 52 • Boom lifting/lowering (67) and movement joystick 52 • Boom telescope out/in (P68) and movement joystick 52 • Turntable rotation (69) and movement joystick 52
4	Drive speed selector : • Low speed selector (57)  and movement joystick 52 • High speed selector (59)  and movement joystick 52
5	Horn selector 62

For HA12CJ (HA33CJ) - HA12CJ+ (HA33CJ+)

Step	Control
1	Driving and steering 33
2	Movements : • Lifting / lowering of boom 49 • Lifting/lowering of arm 247 • Jib lifting/lowering 37 • Boom telescope out/in 246 • Jib rotation 83 (For HA12CJ+ (HA33CJ+)) • Platform rotation selector 38 • Turntable rotation 49 • Platform leveling 40
3	Drive speed selector 45
4	Horn selector 43

For HA16PE only

Step	Control
1	Engine start-up selector 42
2	Driving and rear axle direction 86
3	Front axle steering selector 87
4	Platform rotation selector 38
5	Movements : • Jib lifting/lowering 37 • Platform leveling 40 • Lifting / lowering of boom 49 • Turntable rotation 49 • Lifting/lowering of arm 50 • Boom telescope out/in 54
6	Drive speed selector 71
7	Differential lock selector 35
8	Horn selector 43

E

- Driving

2.3 - PERIODICAL CHECKS

The machine must be inspected on a regular basis at intervals in accordance with the requirements set forth in the Country of use but no less than once per year. The purpose of the inspection is to detect any defect which could lead to an accident during routine use of the machine.

These inspections must be carried out by a competent company or person whose selection is under the responsibility of the manager (Company employee or other).

The inspection results must be recorded in the safety register or machine log book controlled and overseen by the company manager. This register or machine log book and the list of competent repair persons must be made available to the Government Work Inspector and company safety committee at all times.

N.B.:  **SECTION H INTERVENTION REGISTER**

2.4 - REPAIRS AND ADJUSTMENTS

Extensive repairs, interventions or adjustments on the safety systems or elements must be performed by a HAULOTTE Services® employee or a HAULOTTE Services®-approved employee with HAULOTTE Services® training, using original spare parts only.

HAULOTTE Services® technicians are specially trained to carry out extensive repairs, interventions or adjustments on the safety systems or elements of HAULOTTE® machines, and carry genuine HAULOTTE spare parts and tools as required, and also provide fully documented reports on all work completed..

HAULOTTE Services® will not take responsibility for any consequential outcomes resulting from inferior services/repairs carried out by others.

HAULOTTE advises you that NO modifications carried out without the written permission of HAULOTTE® will void the HAULOTTE warranty..

2.5 - INSPECTION / TESTING REQUIREMENTS

Intervention to be made after :

- Extensive dismantling and reassembly.
- Repairs involving the machine's essential components.
- Any accident causing stress to the machine.

Perform a fitness for function inspection, a condition inspection and static and dynamic tests (Consult the After-Sales Service HAULOTTE Services®).

E - Driving

3 - Operation

N.B.:-THE FUNCTIONS ARE DESCRIBED FOR THE ENTIRE RANGE. REFER TO THE MACHINE MODEL TO IDENTIFY THE CONTROLS AND FUNCTIONS INDICATORS.



Find all the function indicators and controls in  Section C 5 - Control boxes

3.1 - TEST PROCEDURE

3.1.1 - Emergency stop button operation

on HA12IP (HA33JE) and HA15IP (HA43JE) only :

N.B.:-THE BATTERY MAIN/ISOLATION SWITCH (SB1) MUST BE PULLED ( SECTION C 5.3 - CONTROL BOXES).

For HA12CJ (HA33CJ) - HA12CJ+ (HA33CJ+) - HA16PE only :

N.B.:-THE BATTERY MAIN/ISOLATION SWITCH MUST BE TURNED.

Ground control box emergency stop button

Step	Action
1	Pull the emergency stop button 15.
3	on HA12IP (HA33JE) and HA15IP (HA43JE) only : Turn and hold the key on the control box activation selector switch (72, 230) to the right to energize the ground control box. The indicators light up. For HA12CJ (HA33CJ) - HA12CJ+ (HA33CJ+) - HA16PE only : Turn the key on the control box activation selector switch (72) to the right to energize the ground control box. The indicators light up.
4	Push the emergency stop button (15). The indicators go out.

Platform control box emergency stop button

Step	Action
1	Pull the emergency stop buttons(15, 46).
2	Turn the key on the control box activation selector switch (72) to the left to energize the platform control box. The indicators light up.
3	Push the emergency stop button (46). The indicators go out.

E - Driving

3.1.2 - Tilt sensor switch operation



For ANSI models only :

Machine unfolded, the slope sensor gives an audible signal telling the operator that the machine should not be deployed. In this case, fully lower the platform and reposition the machine on level ground before raising the platform again.

1. Pull the emergency stop push-buttons on the upper and lower control boxes (15, 46).
2. Switch on the machine from the lower control box (72, 230). All of the ground control box indicators light up and a sound signal (beep) is emitted.
3. Lift the boom, the arm or the jib above the horizontal axis (For HA12IP (HA33JE) - HA15IP (HA43JE) - HA16PE).
4. Locate the tilt sensor next to the ground control box.
5. Manually tilt and maintain the tilt sensor towards the front for a few seconds (Section C 2- Main components) :
 - The audible beep sounds.
 - For machines fitted with : The slope sensor prevents lifting and driving movements.

N.B.-:-MACHINE UNFOLDED, THE SLOPE SENSOR GIVES AN AUDIBLE SIGNAL TELLING THE OPERATOR THAT THE MACHINE SHOULD NOT BE DEPLOYED. IN THIS CASE, FULLY LOWER THE PLATFORM AND REPOSITION THE MACHINE ON LEVEL GROUND BEFORE RAISING THE PLATFORM AGAIN.

3.1.3 - Visual and sound alarms

1. Pull or turn the battery main/isolation switch (SB1) (Section C 5.3 - Control boxes).
2. Pull the emergency stop buttons (15, 46).
3. Select the turntable control box or the platform control box (72, 30,). The indicator (31) of the control box lights up, and there is audible signal (beep).

3.1.4 - Weighing system

1. Pull the emergency stop buttons (15, 46).
2. Switch the machine on (72, 230) :
 - Move to the right : Ground control box
 - Move to the left : Platform control box
 - The platform overload indicators (6, 30) on the platform and ground control boxes and the buzzer warn the operator (If the authorized load on the platform is exceeded).

3.1.5 - Movement safety end of drive contactors

1. Raise the jib to horizontal position and activate high speed. The machine must be in micro-speed (Except HA12CJ (HA33CJ) - HA12CJ+ (HA33CJ+)).
2. Unfold the jib completely and activate high speed. The machine must be in micro-speed (Except HA12CJ (HA33CJ) - HA12CJ+ (HA33CJ+)).
3. Raise the boom slightly above the horizontal position and then activate high speed. The machine must be in micro-speed.
4. Unfold the boom completely and then activate high speed. The machine must be in micro-speed.
5. Raise the arm slightly and then activate high speed. The machine must be in micro-speed.
6. Unfold the arm completely. The machine must be in micro-speed.

E

- Driving

3.2 - OPERATION FROM GROUND POSITION

3.2.1 - Machine start-up

on HA12IP (HA33JE) and HA15IP (HA43JE) only :

1. Pull the battery power (SB1).
2. Pull the emergency stop button 15.
3. Turn and hold the key on the control box activation selector switch (72, 230) to the right to energize the ground control box.

on HA12CJ (HA33CJ) and HA12CJ+ (HA33CJ+) only :

1. Turn the battery main/isolation switch (SB1).
2. Pull the emergency stop button 15.
3. Turn the key on the control box activation selector switch (72) to the right to energize the ground control box.

For HA16PE only :

1. Turn the battery main/isolation switch (SB1).
2. Pull the emergency stop button 15.
3. Turn the key on the control box activation selector switch (72) to the right to energize the ground control box. The following indicators light up :
 - Low engine oil pressure 2.
 - Engine temperature 3.
 - Battery charge 4.
4. The clogged air filter indicator (5) is switched off.
5. Press on the starter selector 22. The engine starts. The indicators go out.
6. Let the engine heat up.

3.2.2 - Machine shutdown

- Turn the key of the control box activation selector (72) to the center.
- The machine is shut down.


E - Driving

3.2.3 - Movement control

For HA12IP (HA33JE) - HA15IP (HA43JE) - Ground control box controls (emergency station)

N.B.:-FOR MACHINES FITTED WITH : HOLD THE SELECTOR (230) TO THE RIGHT TO VALIDATE MOVEMENT. THE RELEASE OF THE SELECTOR CAUSES ALL MOVEMENT TO STOP.

For HA12IP (HA33JE) - HA15IP (HA43JE) - Ground control box controls (emergency station)

Control		Action
Lifting/lowering of arm		Push the arm lift/lower selector (12) upwards to raise the arm.
		Push the arm lift/lower selector (12) downwards to lower the arm.
Lifting / lowering of boom		Push the boom raising selector switch (10) upwards to lift the boom.
		Push the boom raising selector switch (10) downwards to lower the boom.
Boom telescope out/in		Push the boom telescoping selector switch (9) to the left to extend the telescope.
		Push the boom telescoping selector switch (9) to the right to retract the telescope.
Jib lifting/lowering		Push the jib selector switch (8) upwards to lift the jib.
		Push the jib selector switch (8) downwards to lower the jib.
Turntable rotation		Push the turntable rotation switch (14) to the right for an anticlockwise rotation.
		Push the turntable rotation selector switch (14) to the left for a clockwise rotation.
Platform leveling		Push the platform levelling selector switch (13) upwards to lift the platform.
		Push the platform levelling selector switch (13) downwards to lower the platform.

E - Driving

For HA12CJ (HA33CJ) - HA12CJ+ (HA33CJ+) - Ground control box controls (emergency station)

N.B.:-HOLD THE SELECTOR (228) UPWARDS TO VALIDATE MOVEMENT. THE RELEASE OF THE SELECTOR CAUSES ALL MOVEMENT TO STOP.

For HA12CJ (HA33CJ) - HA12CJ+ (HA33CJ+) - Ground control box controls (emergency station)

Control	Action
Lifting/lowering of arm	 Push the arm lift/lower selector (12) upwards to raise the arm. Push the arm lift/lower selector (12) downwards to lower the arm.
Lifting / lowering of boom	 Push the boom raising selector switch (10) upwards to lift the boom. Push the boom raising selector switch (10) downwards to lower the boom.
Boom telescope out/in	 Push the boom telescoping selector switch (9) to the left to extend the telescope. Push the boom telescoping selector switch (9) to the right to retract the telescope.
Jib lifting/lowering	 Push the jib selector switch (8) upwards to lift the jib. Push the jib selector switch (8) downwards to lower the jib.
Turntable rotation	 Push the turntable rotation switch (14) to the right for an anticlockwise rotation. Push the turntable rotation selector switch (14) to the left for a clockwise rotation.
Platform leveling	 Push the platform levelling selector switch (13) upwards to lift the platform. Push the platform levelling selector switch (13) downwards to lower the platform.
Jib rotation	 Push the jib rotation selector switch (74) to the left for a clockwise rotation. Push the jib rotation selector switch (74) to the right for an anticlockwise rotation.

E - Driving

For HA16PE only - Ground control box controls (emergency station)

Control		Action
Lifting/lowering of arm		Push the arm lift/lower selector (12) upwards to raise the arm.
		Push the arm lift/lower selector (12) downwards to lower the arm.
Lifting / lowering of boom		Push the boom raising selector switch (10) upwards to lift the boom.
		Push the boom raising selector switch (10) downwards to lower the boom.
Boom telescope out/in		Push the boom telescoping selector switch (9) to the left to extend the telescope.
		Push the boom telescoping selector switch (9) to the right to retract the telescope.
Jib lifting/lowering		Push the jib selector switch (8) upwards to lift the jib.
		Push the jib selector switch (8) downwards to lower the jib.
Turntable rotation		Push the turntable rotation selector switch (14) to the left for a clockwise rotation.
		Push the turntable rotation switch (14) to the right for an anticlockwise rotation.

N.B.:-THE RELEASE OF THE SELECTOR CAUSES ALL MOVEMENT TO STOP.

3.2.4 - Other controls

- Switching from the ground control box to the platform control box :



The battery main/isolation switch (SB1) and the emergency stop push-button (15) must be pulled or turned.

- Turn the key on the control box activation selector switch (72, 230) to the left to energize the platform control box. The ground control box controls are de-energized.

E - Driving

- Switching from the platform control box to the ground control box :



The emergency stop button (15) must be pulled out.

- on HA12IP (HA33JE) and HA15IP (HA43JE) only : Turn and hold the key on the control box activation selector switch (230) to the right to energize the ground control box. The platform control box controls are de-energized.
- For HA16PE - HA12CJ (HA33CJ) - HA12CJ+ (HA33CJ+) only : Turn the key on the control box activation selector switch (72) to the right to energize the ground control box. The platform control box controls are de-energized.

For HA16PE only

- Engine speed increases :
 - Turn the engine speed selector switch (21) to the right to switch to increase speed.
 - Turn the engine speed selector switch (21) to the left to switch to idling speed.
- For the machines equipped with beacon lights :
 - Push the beacon light selector switch (24) to the right to switch on the beacon light.
 - Push the beacon light selector switch (24) to the left to switch off the beacon light.

3.3 - OPERATIONS FROM THE PLATFORM

3.3.1 - Machine start-up

For HA16PE only

1. Pull the emergency stop button 46.
2. Press on the starter selector 42. The engine starts. The power-up indicator (31) lights up.
3. Let the engine heat up.

N.B.-:-If the engine does not start, switch off the ignition (emergency stop button pushed in). Repeat the start-up procedure.

3.3.2 - Machine shutdown

For HA16PE only :

Press the emergency stop button (46).

3.3.3 - Movement control

For HA12IP (HA33JE) - HA15IP (HA43JE) - Platform control box controls (driving station)



Activate the controls and the 'Enable Switch' system simultaneously to perform the various movements.

E - Driving

For HA12IP (HA33JE) - HA15IP (HA43JE) - Platform control box controls (driving station)

Control		Action
Driving		Push the low or high speed touch pads (59) or (57). Push the drive joystick (52) forwards to move the machine forwards.
		Push the low or high speed touch pads (59) or (57). Push the drive joystick (52) backwards to reverse the machine.
Steering		Push the low or high speed touch pads (59) or (57). Push the drive joystick (52) forwards to move the machine forwards. Push the front-axle steering selector switch (52) to the right to steer to the right.
		Push the low or high speed touch pads (59) or (57). Push the drive joystick (52) forwards to move the machine forwards. Push the front-axle steering selector switch (52) to the left to steer to the left.
Lifting/lowering of arm		Push the arm lift/lower touch pads (66).
		Push the arm lift/lower joystick (52) forwards to raise the arm.
Lifting / lowering of boom		Push the boom lifting touch pads (67).
		Push the boom raising joystick (52) forwards to lift the boom.
Jib lifting/lowering		Push the boom raising joystick (52) backwards to lower the boom.
		Push the jib elevation touch pads (63).
Turntable rotation		Push the jib joystick (52) forwards to raise the jib.
		Push the jib joystick (52) backwards to lower the jib.
Platform rotation		Push the turntable rotation touch pads (69).
		Push the turntable rotation joystick (52) backwards for counter clockwise (CCW) rotation.
Platform rotation		Push the turntable rotation joystick (52) forwards for clockwise rotation.
		Push the platform rotation touch pads (64).
Platform rotation		Push the turntable rotation joystick (52) backwards for counter clockwise (CCW) rotation.
		Push the platform rotation joystick (52) forwards for clockwise rotation.

E - Driving

Control		Action
Platform leveling		Push the platform compensation touch pads (65).
		Push the platform compensation joystick (52) forwards to raise the platform.
		Push the platform compensation joystick (52) backwards to lower the platform.
Drive speed (minimum)		Push the driving speed selector (59) to high speed (long distance driving, tarmac, concrete).
		Push the driving speed selector (57) to for driving in low speed (short distance, final approach, descending from the lorry).
Boom telescope out/in		Push the boom telescope touch pads (68).
		Push the boom telescoping joystick (52) forwards to retract the telescope.
		Push the boom telescoping joystick (52) backwards to extend the telescope.

N.B.:-THE RELEASE OF THE SELECTORS AND (OR) JOYSTICKS CAUSES ALL MOVEMENT TO STOP.

E - Driving

For HA12CJ (HA33CJ) - HA12CJ+ (HA33CJ+) - Platform control box controls (driving station)



Activate the controls and the 'Enable Switch' system simultaneously to perform the various movements.

N.B.:-PRESS AND HOLD THE 'ENABLE SWITCH' PEDAL DOWN TO CONFIRM THE MOVEMENT. MOVEMENTS ARE STOPPED AND PROHIBITED AS A RESULT OF PRESSING THE PEDAL WITHOUT MOTION FOR MORE THAN 7 S OR RELEASING THE PEDAL.

For HA12CJ (HA33CJ) - HA12CJ+ (HA33CJ+) - Platform control box controls (driving station)

Control	Action
Driving	 Push the low or high speed selector 45. Push the drive joystick (33) forwards to move the machine forwards.
	Push the low or high speed selector 45. Push the drive joystick (33) backwards to reverse the machine.
Steering	 Push the low or high speed selector 45. Push the drive joystick (33) forwards to move the machine forwards. Push the front-axle steering selector switch (33) to the right to steer to the right.
	Push the low or high speed selector 45. Push the drive joystick (33) forwards to move the machine forwards. Push the front-axle steering selector switch (33) to the left to steer to the left.
Lifting/lowering of arm	 Push the arm lift/lower selector (247) upwards to raise the arm.
	Push the arm lift/lower selector (247) downwards to lower the arm.
Lifting / lowering of boom	 Push the boom raising joystick (49) forwards to lift the boom.
	Push the boom raising joystick (49) backwards to lower the boom.
Jib lifting/lowering	 Push the jib selector switch (37) forwards to lift the jib.
	Push the jib selector switch (37) back to lower the jib.

E - Driving

Control		Action
Turntable rotation		Push the turntable rotation joystick (49) to the left for a clockwise rotation. Push the turntable rotation joystick (49) to the right for an anticlockwise rotation.
Platform rotation		Push the platform rotation selector (38) to the left for a clockwise rotation. Push the platform rotation selector (38) to the right for an anticlockwise rotation.
Platform leveling		Push the platform levelling selector switch (40) forwards to lift the platform. Push the platform levelling selector switch (40) back to lower the platform.
Drive speed (minimum)		Push the driving speed selector (45) to  high speed (long distance driving, tarmac, concrete). Push the driving speed selector (45) to  for driving in low speed (short distance, final approach, descending from the lorry).
Boom telescope out/in		Push the boom telescoping selector switch (246) to the left to extend the telescope. Push the boom telescoping selector switch (246) to the right to retract the telescope.
Jib rotation (For HA12CJ+ HA33CJ+) only		Push the jib rotation selector switch (83) to the left for a clockwise rotation. Push the jib rotation selector switch (83) to the right for an anticlockwise rotation.

N.B.:-THE RELEASE OF THE SELECTORS AND (OR) JOYSTICKS CAUSES ALL MOVEMENT TO STOP.

E - Driving

For HA16PE - Platform control box controls (driving station)



Activate the controls and the 'Enable Switch' system simultaneously to perform the various movements.

For HA16PE - Platform control box controls (driving station)

Control	Action
Driving 	Push the drive joystick (86) forwards to move the machine forwards.
	Push the drive joystick (86) backwards to reverse the machine.
Rear-axle steering 	Push the rear axle steering selector to the right (86) to steer to the right
	Press to the left of the rear axle steering selector (86) to steer to the left
Front-axle steering 	Push the front-axle steering selector switch (87) to the right to steer to the right.
	Push the front-axle steering selector switch (87) to the left to steer to the left.
Jib lifting/lowering 	Push the jib selector switch (37) upwards to lift the jib.
	Push the jib selector switch (37) downwards to lower the jib.
Lifting / lowering of boom 	Push the boom raising joystick (49) upwards to lift the boom.
	Push the boom raising joystick (49) downwards to lower the boom.
Turntable rotation 	Push the turntable rotation selector switch (49) to the left for a clockwise rotation.
	Push the turntable rotation switch (49) to the right for an anticlockwise rotation.

E - Driving

Control		Action
Platform rotation		Push the platform rotation selector (38) to the right for an anticlockwise rotation. Push the platform rotation selector (38) to the left for a clockwise rotation.
Platform leveling		Raise the safety cover. Push the platform levelling selector switch (40) upwards to lift the platform. Raise the safety cover. Push the platform levelling selector switch (40) downwards to lower the platform.
Drive speed (minimum)		Set the drive speed selector switch (71) to for high-speed driving (long distance driving, tarmac, concrete). Position the driving speed selector (71) on for medium speed driving (crossing uneven ground, slope). Set the driving speed selector (71) to for low-speed driving (short distance, final approach, unloading from lorries).
Boom telescope out/in		Push the boom telescoping selector switch (54) to the left to extend the telescope. Push the boom telescoping selector switch (54) to the right to retract the telescope.
Lifting/lowering of arm		Push the arm lift/lower joystick (50) forwards to raise the arm. Push the arm lift/lower joystick (50) backwards to lower the arm.

N.B.-:-THE RELEASE OF THE SELECTORS AND (OR) JOYSTICKS CAUSES ALL MOVEMENT TO STOP.

E - Driving

3.3.4 - Other controls

For : HA16PE - HA12CJ (HA33CJ) - HA12CJ+ (HA33CJ+)

- Horn : Push the horn selector (43) to the right to sound the horn.

N.B.-:-THE HORN STOPS WHEN THE SELECTOR SWITCH IS RELEASED.

For : HA12IP (HA33JE) - HA15IP (HA43JE)

- Horn : Press the Horn switch (62) to sound the horn.

F

- Special procedure



Find all the function indicators and controls in  Section C 5 - Control boxes

1 - Emergency lowering

1.1 - PRINCIPLE

Emergency lowering is required if the operator in the platform is no longer capable of controlling the movements even though the machine operates normally.

A ground operator trained in using the emergency controls and in possession of the starter key can use the ground control box with the main power source to lower the platform operator.

1.2 - PROCEDURE

 Section A 2- Pre-operation instructions

1. Turn the key on the control box activation selector switch (72) to the right to energize the ground control box. The platform control box controls are de-energized.
2. Lower the platform from the ground control box.



If the machine is stuck or hooked in surrounding structures or equipment, it is essential to release the operators before intervening on the machine.

2 - Lowering for repairs

2.1 - PRINCIPLE

The lowering for repairs function allows the operator to be lowered to the ground in case of failure of the main power source.

2.2 - PROCEDURE


For HA12IP (HA33JE) - HA15IP (HA43JE) - HA16PE :

There is a way of performing movements from the ground, when the main energy source malfunctions. It is a hand pump located next to the hydraulic distributors on the turntable.

F - Special procedure

This pump can be used in combination with a manual override multi bank electro-hydraulic valve, to perform the movement required to lower the platform :

- Boom lowering.
 - Boom lowering.
 - To telescope in
 - Turntable rotation.
 - Platform rotation.
 - Jib lowering.
1. Insert the lever (1) in the socket of the pump.
 2. Check that the pump depressurizing valve (2) is in closed position.
 3. Push the lever from top to bottom several times whilst keeping the manual electro-distributor control for the requirement movement shown on the plate pressed in and held in 3



For HA12CJ (HA33CJ) - HA12CJ+ (HA33CJ+) :

There is a way of performing movements from the ground, when the main energy source malfunctions. This involves a hand pump located at the base of the hydraulic unit on the turntable.


This pump can be used in combination with a manual override multi bank electro-hydraulic valve, to perform the movement required to lower the platform :

- Boom lowering.
- Boom lowering.
- To telescope in
- Turntable rotation.
- Jib lowering.

F

- Special procedure

4. Insert the lever (1) in the return bend of the pump (3).
5. Push the lever from left to right several times whilst keeping down the manual electro-distributor control (2) for the required movement, as shown on the plate (A74).



N.B.:-SOME LIFTING MOVEMENTS MAY BE PERFORMED IN ORDER TO AVOID PARTICULAR OBSTACLES.

N.B.:-AN ELECTRIC EMERGENCY PUMP IS AVAILABLE AS AN OPTION. IT REPLACES THE MAIN PUMP IN CASE OF A MALFUNCTION. DEPENDING ON THE CONTROL BOX USED, PUSH AND HOLD THE BACK-UP HYDRAULIC POWER SYSTEM SELECTOR SWITCH ((228) DOWNWARDS OR (41) UPWARDS) AND LOWER THE PLATFORM.



If the operator in the platform has to exit the platform when elevated, he must exit onto a sturdy, safe structure, the transfer must respect the following recommendations :

- The operator must secure himself by using 2 straps. One lanyard is attached to the platform, the other to the structure onto which he wishes to exit.
- The operator must exit the platform via the standard access point.
- The operator must not detach the strap connected to the platform until transfer is complete or while the transfer still presents a danger.



If the operator cannot be lowered by any of the above mentioned methods, contact HAULOTTE Services® immediately.

F

- Special procedure

3 - Towing

In case of a machine failure, it is possible to tow it to load it onto a trailer.

3.1 - DISSENGAGING THE DRIVE HUBS

To tow a broken-down machine, disconnect the wheel drive hubs.



Perform these operations on flat, horizontal ground. Failing that, block the wheels to immobilize the machine. During an operation of disengaging the drive hubs, the machine is in free wheels, the brake system no longer functions.

For : HA16PE

Unscrew the central nut (1) until the nut is at the limit.



For : HA12IP (HA33JE) - HA15IP (HA43JE)

Unscrew the central nut until the nut is at the limit.

As soon as there is resistance, do not force further to avoid breaking the central nut in the reducer.



For : HA12CJ (HA33CJ) - HA12CJ+ (HA33CJ+)

Unscrew the 2 nuts with an 11 mm spanner.



Turn the part and screw it back on.



F

- Special procedure

The gears are released.



3.2 - REENGAGING THE DRIVE HUBS

After repairing the machine, reengage the wheel drive hubs.

For : HA12IP (HA33JE) - HA15IP (HA43JE)

Tighten the central reducer nut (1).

For : HA12CJ (HA33CJ) - HA12CJ+ (HA33CJ+)

Perform in reverse order to the drive hub disengaging procedure.

For : HA16PE

- Screw the central nut up again to engage the internal gear.
- Engage the driving gear slowly in case of resistance.
- Screw the central nut up completely when the once the drive gear has commenced to engage.

N.B.: - IN THE EVENT THAT RESISTANCE TO GEAR ENGAGEMENT IS FELT, PERFORM THE MACHINE DRIVE FUNCTION TO SLOWLY MOVE THE INTERNAL HUB GEAR TO A MESH POSITION WHERE BOTH GEARS WILL ENGAGE ; THEN SCREW THE CENTRAL NUT IN FULLY.

F

- Special procedure

4 - Loading and unloading

N.B.:-WHEN DRIVING UP AN INCLINE OR RAMP, DURING LOADING OR UNLOADING HAULOTTE® RECOMMENDS POSITIONING THE COUNTERWEIGHT AT THE REAR.

on HA12CJ (HA33CJ) and HA12CJ+ (HA33CJ+) only :

N.B.:-WHEN DRIVING UP AN INCLINE OR RAMP, DURING LOADING OR UNLOADING HAULOTTE® RECOMMENDS POSITIONING THE DRIVE AXLE BELOW THE STEERED AXLE.



Raise the platform sufficiently to avoid contact with the ground.



To avoid any risk of tipping over, the boom must be maintained in the longitudinal axis of the chassis.



Section F 4.2 Putting in transport position.

4.1 - PRINCIPLE



To avoid any risk of sliding during loading, ensure that :

- The loading ramps can bear the load.
- The loading ramps are correctly attached.
- The loading ramp has sufficient grip.

Since the gradient of the slope usually exceeds the authorized limit for an unfolded machine in the normal operational mode, the arm and boom must be lowered and retracted to allow travel up the ramp.

In this case, the buzzer is not activated and driving is authorised.



For HA16PE :

To climb the slope, select low driving speed .

For HA12IP (HA33JE), HA15IP (HA43JE), HA12CJ (HA33CJ) and HA12CJ+ (HA33CJ+) only :

Select the high driving speed  to climb the slope

If the slope is too steep, use a winch in addition to traction.



Never place yourself below or too close to the machines during loading.

A wrong move can lead to the tipping over of the machine and cause serious bodily and material accidents.


4.1.1 - Loading by lifting

Ensure that :

- The machine is completely stowed.
- The platform must be empty.
- The lifting equipment ie. slings, shackles, hooks, lifting beam etc. are in good condition and of sufficient capacity.
- The personnel performing the lift is authorised to complete the lift.

F - Special procedure

Procedure for the use of slings



A	20 cm mini (min.) / 8 in mini (min.)
B	• 4 hoisting slings 5 m (16 ft 5 in) in length • Maximum load per sling and shackle : 5000 daN (11241 lbf)



Before using slings, lift the jib to obtain a minimum 20 cm (8in) clearance between the ground and cage

4.2 - PUTTING IN TRANSPORT POSITION

The machine must be completely stowed.



1. Check the platform is completely empty.
2. Raise the boom sufficiently.
3. Depending on the configuration of the machine, engage the transport position selector (13) to the right.
4. Lower the boom without forcing (for fear of damaging the platform).
5. Secure the machine to the anchorage points provided for this purpose (See Figure below).
6. Block the turntable with the rotation stop pin located under the turntable.





Do not transport the machine if the turntable is not locked.

F - Special procedure

For : HA12IP (HA33JE) - HA15IP (HA43JE) - HA16PE



For : HA12CJ (HA33CJ) - HA12CJ+ (HA33CJ+)



F

- Special procedure

Loading characteristics

Marking	Description	HA12IP (HA33JE)	HA15IP (HA43JE)
B	Lateral distance between the wheels	1,80 m(5 ft10 in)	2,00 m(6 ft6 in)
C	Front wheel ground pressure	10,4 daN/cm ² (2,13 lbf/sq.ft)	8,6 daN/cm ² (1,76 lbf/sq.ft)
D	Rear wheel ground pressure	10,4 daN/cm ² (2,13 lbf/sq.ft)	8,6 daN/cm ² (1,76 lbf/sq.ft)
	Anchorage point		
	Turntable rotation locking		

Loading characteristics

Marking	Description	HA16PE
B	Lateral distance between the wheels	2,00 m(6 ft6 in)
C	Front wheel ground pressure	7,6 daN/cm ² (1,56 lbf/sq.ft)
D	Rear wheel ground pressure	7,6 daN/cm ² (1,56 lbf/sq.ft)
	Anchorage point	
	Turntable rotation locking	

Loading characteristics

Marking	Description	HA12CJ (HA33CJ)	HA12CJ+ (HA33CJ+)
B	Lateral distance between the wheels	1,65 m(5 ft5 in)	1,65 m(5 ft5 in)
C	Front wheel ground pressure	17,5 daN/cm ² (3,58 lbf/sq.ft)	17,5 daN/cm ² (3,58 lbf/sq.ft)
D	Rear wheel ground pressure	17,5 daN/cm ² (3,58 lbf/sq.ft)	17,5 daN/cm ² (3,58 lbf/sq.ft)
	Anchorage point		
	Turntable rotation locking		

F - Special procedure

4.3 - UNLOADING



Before operating, check that the machine is in good condition.

If the machine has been damaged during transportation, contact the transporter in writing.

1. Unlock the turntable rotation locking pin.
2. Remove the tie downs.
3. Start the machine.

4.4 - WARNING



Upon starting a machine that has been secured then transported, the safety system may detect a false overload forbidding all movement from the platform control box.

To reinstate the system, lift the jib a few centimetres from the ground control box.

For : HA12IP (HA33JE) - HA15IP (HA43JE) - HA12CJ (HA33CJ) - HA12CJ+ (HA33CJ+)

If the machine was transported in the transport position :

Push the transport position selector (13) to the left to set the machine to operating position.

To unload the machine, select low driving speed .



Do not travel down the ramp at a fast speed.

4.5 - STORAGE



The machine must always be powered up when it is unfolded so that the security systems are active.

This means that the machine must be parked in stowed position.

The boom may be raised but it cannot be telescoped.

We strongly advise you not to store or immobilize the machine unfolded to avoid jeopardising the safety of people and property.

G

- Technical characteristics

1 - Main characteristics



Certain options can modify the machine's operating characteristics and its associated safety. If your machine was originally delivered with options fitted, replacing a safety component associated with a particular options not require any particular precautions other than those associated with the installation itself (static test).

Otherwise, it is essential to follow the manufacturer's recommendations below :

- Installation by authorised HAULOTTE® personnel only.
- Update the manufacturer's identification plate.
- Have stability tests carried out by a certified agency/competent person.
- Ensure label compliance.



HAULOTTE® has a continuous improvement policy in place for its product range ; Given this policy, The Company reserves the right to modify their product technical characteristics without notice.



The hand and feet vibration and noise level values indicated in the technical characteristics tables are obtained in the following conditions :

- The maximum quadratic mean value weighted as an acceleration frequency and the total value of the vibrations to which the hand-arm system is exposed have been measured on the products by simulating a cycle representative of normal use. The values meet the requirements of the 2006/42/CE machine directive.
- For electric machines, the sound power level is measured at the drive station under the conditions described by the 2006/42/CE machine directive.
- For machines equipped with internal combustion engines, the noise level guarantees (LWA displayed on the product) and is measured in accordance with the method and the conditions described in Appendix III, Part B, Method 1 and 0 of the 2000/14/CE European directive.

G - Technical characteristics

For HA12IP (HA33JE) - Technical characteristics

Machine Characteristics	HA12IP		HA33JE	
	Metric	Imperial	Metric	Imperial
Overall width of machine	1,35 m	(4 ft5 in)	1,35 m	(4 ft5 in)
Maximum ground clearance	0,15 m	(0 ft5 in)	0,15 m	(0 ft5 in)
Transport height	2,00 m	(6 ft6 in)	2,00 m	(6 ft6 in)
Transport length	5,45 m	(17 ft10 in)	5,45 m	(17 ft10 in)
Maximum work height	12,00 m	(39 ft4 in)	12,00 m	(39 ft4 in)
Maximum platform height	10,00 m	(32 ft9 in)	10,00 m	(32 ft9 in)
Maximum work radius	6,63 m	(21 ft9 in)	6,63 m	(21 ft9 in)
Turntable rotation	355 °			
Jib working range	+70° / - 70°			
Platform length	0,80 m	(2 ft7 in)	0,80 m	(2 ft7 in)
Platform width	1,20 m	(3 ft11 in)	1,20 m	(3 ft11 in)
Outer turning radius	2,85 m	(9 ft4 in)	2,85 m	(9 ft4 in)
Inner turning radius	2,50 m	(8 ft2 in)	2,50 m	(8 ft2 in)
Tilt CE-AS compliant machines	3 °			
Rated slope ANSI-CSA compliant machines	0 °			
Slope warning ANSI-CSA compliant machines	5 °			
Maximum wind speed allowed	45 km/h	(28 mph)	45 km/h	(28 mph)
Total weight	5900 kg	(13007 lb)	5900 kg	(13007 lb)
Maximum platform load	230 kg	(507 lb)	230 kg	(507 lb)
Maximum number of people on the platform	2			
Engine type	Electric			
Hydraulic oil tank capacity	30 l	(7.9 gal US)	30 l	(7.9 gal US)
Operating batteries	48 V-375 Ah			
Operating batteries (Option)	48 V-360 Ah			
Differential lock	Yes			
Maximum climbable slope	25 %			
Tyre type and/ or size	7.00" - 12"		7.00" - 12"	
Maximum ground pressure on hard ground	10,4 daN/cm ²	2,13 lbf/sq.ft	10,4 daN/cm ²	2,13 lbf/sq.ft
Maximum ground pressure on soft ground	7,2 daN/cm ²	1,47 lbf/sq.ft	7,2 daN/cm ²	1,47 lbf/sq.ft
Micro drive speed	0,9 km/h	(0,56 mph)	0,7 km/h	(0,4 mph)
Low drive speed	2,2 km/h	(1,37 mph)	2,3 km/h	(1,4 mph)
High drive speed	4,5 km/h	(2,8 mph)	5,0 km/h	(3,1 mph)
Hand vibration	<2,5 m/s ²	(98 in/s ²)	<2,5 m/s ²	(98 in/s ²)
Feet vibration	<0,5 m/s ²	(19 in/s ²)	<0,5 m/s ²	(19 in/s ²)
Noise emission level	< 70 dB (A)			
Manual lateral force at platform	CE-AS compliant machines : 400 N - 90 lbf		ANSI-CSA compliant machines : 666 N / 150 lbf	

G


- Technical characteristics

For HA15IP (HA43JE) - Technical characteristics

Machine	HA15IP		HA43JE	
Characteristics	Metric	Imperial	Metric	Imperial
Overall width of machine	1,50 m	(4 ft11 in)	1,50 m	(4 ft11 in)
Maximum ground clearance	0,15 m	(0 ft5 in)	0,15 m	(0 ft5 in)
Transport height	2,10 m	(6 ft11 in)	2,00 m	(6 ft6 in)
Transport length	6,60 m	(21 ft7 in)	6,60 m	(21 ft7 in)
Maximum work height	15,00 m	(49 ft2 in)	15,00 m	(49 ft2 in)
Maximum platform height	13,00 m	(42 ft7 in)	13,00 m	(42 ft7 in)
Maximum work radius	8,45 m	(27 ft8 in)	8,45 m	(27 ft8 in)
Turntable rotation	350 °			
Jib working range	+70° / - 70°			
Platform length	0,80 m	(2 ft7 in)	0,80 m	(2 ft7 in)
Platform width	1,20 m-1,50 m	(3 ft11 in)-(4 ft11 in)	1,20 m-1,50 m	(3 ft11 in)-(4 ft11 in)
Outer turning radius (without retracted axle adjustment)	3,70 m	(12 ft1 in)	3,70 m	(12 ft1 in)
Inner turning radius (with axles retracted)	1,70 m	(5 ft6 in)	1,70 m	(5 ft6 in)
Tilt CE-AS compliant machines	3 °			
Rated slope ANSI-CSA compliant machines	0 °			
Slope warning ANSI-CSA compliant machines	5 °			
Maximum wind speed allowed	45 km/h	(28 mph)	45 km/h	(28 mph)
Total weight	7300 kg	(16094 lb)	7300 kg	(16094 lb)
Maximum platform load	230 kg	(507 lb)	230 kg	(507 lb)
Maximum number of people on the platform	2			
Engine type	Electric			
Hydraulic oil tank capacity	30 l	(7.9 gal US)	30 l	(7.9 gal US)
Operating batteries	48 V-360 Ah			
Operating batteries (Option)	48 V-360 Ah			
Differential lock	Yes			
Maximum climbable slope	25 %			
Tyre type and/ or size	23.10" - 12"			
Maximum ground pressure on hard ground	8,6 daN/cm ²	1,76 lbf/sq.ft	8,6 daN/cm ²	1,76 lbf/sq.ft
Maximum ground pressure on soft ground	6,3 daN/cm ²	1,29 lbf/sq.ft	6,3 daN/cm ²	1,29 lbf/sq.ft
Low drive speed	2,3 km/h	(1,4 mph)	2,3 km/h	(1,4 mph)
High drive speed	5 km/h	(3,11 mph)	4,5 km/h	(2,8 mph)
Hand vibration	<2,5 m/s ²	(98 in/s ²)	<2,5 m/s ²	(98 in/s ²)
Feet vibration	<0,5 m/s ²	(19 in/s ²)	<0,5 m/s ²	(19 in/s ²)
Noise emission level	< 70 dB (A)			
Manual lateral force at platform	CE-AS compliant machines : 400 N - 90 lbf		ANSI-CSA compliant machines : 666 N / 150 lbf	

G - Technical characteristics

For HA12CJ (NA) - Technical characteristics

Machine	HA12CJ		HA33CJ	
Characteristics	Metric	Imperial	Metric	Imperial
Overall length of machine	5,36 m	(17 ft7 in)	5,36 m	(17 ft7 in)
Overall width of machine	1,20 m	(3 ft11 in)	1,20 m	(3 ft11 in)
Overall height of machine	1,99 m	(6 ft6 in)	1,99 m	(6 ft6 in)
Minimum ground clearance	0,04 m	(0 ft2 in)	0,04 m	(0 ft2 in)
Maximum ground clearance	0,11 m	(0 ft4 in)	0,11 m	(0 ft4 in)
Cage ground clearance in stowed position	0,35 m	(1 ft2 in)	0,35 m	(1 ft2 in)
Platform length in transport position	3,86 m	(12 ft8 in)	3,86 m	(12 ft8 in)
Platform height in transport position	2,22 m	(7 ft3 in)	2,22 m	(7 ft3 in)
Overall width at standard tyre level	1,20 m	(3 ft11 in)	1,20 m	(3 ft11 in)
Maximum work height	11,70 m	(38 ft5 in)	11,70 m	(38 ft5 in)
Maximum floor elevation height	9,70 m	(31 ft10 in)	9,70 m	(31 ft10 in)
Maximum working overhang above ground	6,94 m	(22 ft9 in)	6,94 m	(22 ft9 in)
Maximum height of pivot point	4,74 m	(15 ft7 in)	4,74 m	(15 ft7 in)
Maximum span of cage above ground	6,44 m	(21 ft2 in)	6,44 m	(21 ft2 in)
Turntable rotation	355 °			
Boom rotation angle	83 °			
Jib working range	+63.5° / - 68.7°			
Horizontal jib rotation	+90° / - 90°			
Length of jib movement with horizontal cage	2,45 m	(8 ft0 in)	2,45 m	(8 ft0 in)
Height of jib movement at cage end	2,31 m	(7 ft7 in)	2,31 m	(7 ft7 in)
Cage overall length	0,8 m	(2 ft7 in)	0,8 m	(2 ft7 in)
Cage overall width	1,14 m	(3 ft9 in)	1,14 m	(3 ft9 in)
Cage overall height	1,1 m	(3 ft7 in)	1,1 m	(3 ft7 in)
Cage rotation angle	+90° / - 90°			
Outer turning radius	Right : 3,60 m	Right : (11 ft10 in)	Right : 3,60 m	Right : (11 ft10 in)
	Left : 3,60 m	Left : (11 ft10 in)	Left : 3,60 m	Left : (11 ft10 in)
Inner turning radius	Right : 1,95 m	Right : (6 ft5 in)	Right : 1,95 m	Right : (6 ft5 in)
	Left : 1,95 m	Left : (6 ft5 in)	Left : 1,95 m	Left : (6 ft5 in)
Space requirement for turning radius	Right : 3,60 m	Right : (11 ft10 in)	Right : 3,60 m	Right : (11 ft10 in)
	Left : 3,60 m	Left : (11 ft10 in)	Left : 3,60 m	Left : (11 ft10 in)
Tyre width	0,19 m	(0 ft7 in)	0,19 m	(0 ft7 in)
Wheelbase	1,65 m	(5 ft5 in)	1,65 m	(5 ft5 in)
Tyre diameter	0,6 m	(2 ft0 in)	0,6 m	(2 ft0 in)
Tyre size	600 x 190			
Compliance with standards				
Tilt CE-AS compliant machines	3 °			
Rated slope ANSI-CSA compliant machines	0 °			
Slope warning ANSI-CSA compliant machines	5 °			

G

- Technical characteristics

A

B

C

D

E

F

G

H

I

Machine	HA12CJ		HA33CJ	
Characteristics	Metric	Imperial	Metric	Imperial
Load moment indicator	Fixed potholes			
Maximum wind speed allowed	45 km/h	(54.7 mph)	45 km/h	(54.7 mph)
Total weight	6970 kg	(15.369 lb)	6970 kg	(15.369 lb)
Maximum load capacity	250 kg	(551 lb)	250 kg	(551 lb)
Battery types	Standard : Semi traction Option : Traction			
Battery voltage	48 V			
Battery capacity	320 Ah (C5)			
Maximum climbable slope	25 %			
Wheel nut torque	21 daN.m	(154 lbf.ft)	21 daN.m	(154 lbf.ft)
Slew ring torque	9 daN.m	(66 lbf.ft)	9 daN.m	(66 lbf.ft)
Maximum ground pressure on hard ground	17,5 daN/cm ²	3.58 lb/ft ²	17,5 daN/cm ²	3.58 lb/ft ²
Maximum ground pressure on soft ground	15 daN/cm ²	3.073 lb/ft ²	15 daN/cm ²	3.073 lb/ft ²
Micro drive speed	0,68 km/h	(0.42 mph)	0,68 km/h	(0.42 mph)
Low drive speed	3 km/h	(1.86 mph)	3 km/h	(1.86 mph)
High drive speed	6 km/h	(3.72 mph)	6 km/h	(3.72 mph)
Hydraulic oil tank capacity	13,5 l	(2.97 gal US)	13,5 l	(2.97 gal US)

G - Technical characteristics

For HA12CJ+ (HA33CJ+) - Technical characteristics

Machine	HA12CJ+		HA33CJ+	
Characteristics	Metric	Imperial	Metric	Imperial
Overall length of machine	5,64 m	(18 ft6 in)	5,64 m	(18 ft6 in)
Overall width of machine	1,20 m	(3 ft11 in)	1,20 m	(3 ft11 in)
Overall height of machine	1,99 m	(6 ft6 in)	1,99 m	(6 ft6 in)
Minimum ground clearance	0,04 m	(0 ft2 in)	0,04 m	(0 ft2 in)
Maximum ground clearance	0,11 m	(0 ft4 in)	0,11 m	(0 ft4 in)
Cage ground clearance in stowed position	0,35 m	(1 ft2 in)	0,35 m	(1 ft2 in)
Platform length in transport position	4,2 m	(13 ft9 in)	4,2 m	(13 ft9 in)
Platform height in transport position	2,6 m	(8 ft6 in)	2,6 m	(8 ft6 in)
Overall width at standard tyre level	1,20 m	(3 ft11 in)	1,20 m	(3 ft11 in)
Maximum work height	11,70 m	(38 ft5 in)	11,70 m	(38 ft5 in)
Maximum floor elevation height	9,70 m	(31 ft10 in)	9,70 m	(31 ft10 in)
Maximum working overhang above ground	7,22 m	(23 ft8 in)	7,22 m	(23 ft8 in)
Maximum height of pivot point	4,74 m	(15 ft7 in)	4,74 m	(15 ft7 in)
Maximum span of cage above ground	6,72 m	(22 ft1 in)	6,72 m	(22 ft1 in)
Turntable rotation	355 °			
Boom rotation angle	83 °			
Jib working range	+63.5° / - 68.7°			
Horizontal jib rotation	+90° / - 90°			
Length of jib movement with horizontal cage	2,45 m	(8 ft0 in)	2,45 m	(8 ft0 in)
Height of jib movement at cage end	2,31 m	(7 ft7 in)	2,31 m	(7 ft7 in)
Cage overall length	0,8 m	(2 ft7 in)	0,8 m	(2 ft7 in)
Cage overall width	1,14 m	(3 ft9 in)	1,14 m	(3 ft9 in)
Cage overall height	1,1 m	(3 ft7 in)	1,1 m	(3 ft7 in)
Cage rotation angle	+90° / - 90°			
Outer turning radius	Right : 3,60 m	Right : (11 ft10 in)	Right : 3,60 m	Right : (11 ft10 in)
	Left : 3,60 m	Left : (11 ft10 in)	Left : 3,60 m	Left : (11 ft10 in)
Inner turning radius	Right : 1,95 m	Right : (6 ft5 in)	Right : 1,95 m	Right : (6 ft5 in)
	Left : 1,95 m	Left : (6 ft5 in)	Left : 1,95 m	Left : (6 ft5 in)
Space requirement for turning radius	Right : 3,60 m	Right : (11 ft10 in)	Right : 3,60 m	Right : (11 ft10 in)
	Left : 3,60 m	Left : (11 ft10 in)	Left : 3,60 m	Left : (11 ft10 in)
Tyre width	0,19 m	(0 ft7 in)	0,19 m	(0 ft7 in)
Wheelbase	1,65 m	(5 ft5 in)	1,65 m	(5 ft5 in)
Tyre diameter	0,6 m	(2 ft0 in)	0,6 m	(2 ft0 in)
Tyre size	600 x 190			
Compliance with standards				
Tilt CE-AS compliant machines	3 °			
Rated slope ANSI-CSA compliant machines	0 °			
Slope warning ANSI-CSA compliant machines	5 °			

G

- Technical characteristics

Machine	HA12CJ+		HA33CJ+	
Characteristics	Metric	Imperial	Metric	Imperial
Load moment indicator	Fixed potholes			
Maximum wind speed allowed	45 km/h	(54.7 mph)	45 km/h	(54.7 mph)
Total weight	7040 kg	(15.523 lb)	7240 kg	(15.964 lb)
Maximum load capacity	230 kg	(507 lb)	230 kg	(507 lb)
Battery types	Standard : Semi traction Option : Traction			
Battery voltage	48 V			
Battery capacity	320 Ah (C5)			
Maximum climbable slope	25 %			
Wheel nut torque	21 daN.m	(154 lbf.ft)	21 daN.m	(154 lbf.ft)
Slew ring torque	9 daN.m	(66 lbf.ft)	9 daN.m	(66 lbf.ft)
Maximum ground pressure on hard ground	17,5 daN/cm ²	3.58 lb/ft ²	17,5 daN/cm ²	3.58 lb/ft ²
Maximum ground pressure on soft ground	15 daN/cm ²	3.073 lb/ft ²	15 daN/cm ²	3.073 lb/ft ²
Micro drive speed	0,68 km/h	(0.42 mph)	0,68 km/h	(0.42 mph)
Low drive speed	3 km/h	(1.86 mph)	3 km/h	(1.86 mph)
High drive speed	6 km/h	(3.72 mph)	6 km/h	(3.72 mph)
Hydraulic oil tank capacity	13,5 l	(2.97 gal US)	13,5 l	(2.97 gal US)

G - Technical characteristics

For HA16PE - Technical characteristics


Machine Characteristics	HA16PE	
	Metric	Imperial
Length of machine in stowed position	6,65 m	(21 ft9 in)
Overall width of machine	1,83 m	(6 ft0 in)
Machine height	2,20 m	(7 ft2 in)
Maximum ground clearance	0,265 m	(0 ft10 in)
Maximum work height	16,10 m	(52 ft9 in)
Maximum platform height	14,10 m	(46 ft3 in)
Maximum work radius	9,10 m	(29 ft10 in)
Turntable rotation	350 °	
Boom rotation angle	+75° / - 0°	
Outer turning radius (without retracted axle adjustment)	3,50 m	(11 ft5 in)
Distance between centres of the wheels	2,00 m	(6 ft6 in)
Dumping	5 °	
Maximum wind speed allowed	45 km/h	(28 mph)
Total weight	7885 kg	(17383 lb)
Maximum platform load	250 kg	(551 lb)
Maximum number of people on the platform	2	
Engine type	Diesel - Deutz F3L1011F	
Engine power	28 kW	(28 Hp)
Engine power when idle	15 kW	(12 Hp)
Fuel consumption when idle	230 g/kWh	
Hand vibration	<2,5 m/s ²	(98 in/s ²)
Feet vibration	<0,5 m/s ²	(19 in/s ²)
Fuel tank capacity	65 l	(17.17 gal US)
Hydraulic oil tank capacity	100 l	(22 gal US)
Operating batteries	12 V-95 Ah	
Differential lock	Yes	
Maximum climbable slope	25 %	
Tyre type and/ or size	245/80 - R19,5	
Wheel nut torque	(236 lbf.ft)	
Slew ring torque	21,5 daN.m	(159 lbf.ft)
Maximum ground pressure on hard ground	7,6daN/cm ²	1,56 lbf/sq.ft
Maximum ground pressure on soft ground	6,1daN/cm ²	1,25 lbf/sq.ft
Low drive speed	1,5 km/h	(0.9 mph)
Medium-speed driving	3,0 km/h	(1.8 mph)
High drive speed	6,0 km/h	(3.6 mph)
Sound level at 10 m	< 74 dB (A)	
Noise emission level	107 dB (A)	
Manual lateral force at platform	CE-AS compliant machines : 400 N - 90 lbf	

G

- Technical characteristics

2 - Overall dimensions

General diagram HA12IP (HA33JE)




Overall dimension specifications

Marking	HA12IP (HA33JE)	
	Mètre	Feet inch
A	5,45	17 ft 10 in
B	1,35	4 ft 5 in
C	2	6 ft 7 in
D	1,80	5 ft 10 in
E	0,15	0 ft 5 in
F x G	1,20 x 0,80	3 ft 11 in x 2 ft 7 in
J	2,00	6 ft 7 in

G - Technical characteristics

General diagram HA15IP (HA43JE)




Overall dimension specifications

Marking	HA15IP (HA43JE)	
	Mètre	Feet inch
A	6,60	21 ft 7 in
B	1,50	4 ft 11 in
C	2,10	6 ft 11 in
E	0,15	0 ft 5 in
F x G	1,20/1,50 x 0,80	3 ft 11 in / 4 ft 11 in x 2 ft 7 in
J	2,10	6 ft 11 in

G

- Technical characteristics

General diagram HA12CJ (HA33CJ) - HA12CJ+ (HA33CJ+)




Overall dimension specifications

Marking	HA12CJ (HA33CJ)		HA12CJ+ (HA33CJ+)	
	Mètre	Feet inch	Mètre	Feet inch
A	5,36	17 ft 7 in	5,64	18 ft 6 in
B	1,20	3 ft 11 in	1,20	3 ft 11 in
C	1,99	6 ft 6 in	1,99	6 ft 6 in
D	1,65	5 ft 5 in	1,65	5 ft 5 in
E	0,11	0 ft 4 in	0,11	0 ft 4 in
F x G	1,14 x 0,80	3 ft 9 in x 2 ft 7 in	1,14 x 0,80	3 ft 9 in x 2 ft 7 in
H	3,86	12 ft 8 in	4,20	13 ft 9 in
J	2,22	7 ft 3 in	2,60	8 ft 6 in

G - Technical characteristics

General diagram HA16PE



Overall dimension specifications

Marking	HA16PE	
	Mètre	Feet inch
A	6,65	21 ft 9 in
B	1,83	6 ft 0 in
D	2,00	6 ft 7 in
E	0,265	0 ft 10 in
F x G	1,50 x 0,80	4 ft 11 in x 2 ft 7 in


G

- Technical characteristics

3 - Working area

3.1 - MACHINE HA12IP (HA33JE)


Working area



G - Technical characteristics

3.2 - MACHINE HA15IP (HA43JE)


Working area



G - Technical characteristics

3.3 - MACHINE HA12CJ (HA33CJ)


Working area



G - Technical characteristics

3.4 - MACHINE HA12CJ+ (HA33CJ+)

Working area




G

- Technical characteristics

3.5 - MACHINE HA16PE

Working area



G

- Technical characteristics

4 - AS - CE standard specificities

The following tests must be performed after :

- A major technical intervention.
- An accident due to major component failure on the machine.



- The following tests must be performed by a qualified person in secure conditions.
- The results must be fully recorded.



To avoid the machine tipping over, it must be secured during the test (by a chain or anchorage point).

4.1 - OVERLOAD TEST

The overload test is performed with 125 % of the nominal load. See paragraph 1.12.3 of the AS1418.10 standard for test details.

Load table

Machine	Test load	
	Pound (lb)	Kilogramme (kg)
HA12IP (HA33JE)	634	287,5
HA15IP (HA43JE)	634	287,5
HA16PE	688	312.5
HA12CJ	662	300
HA12CJ+	633	287



The machine must not show any signs of permanent distortion.

Tests are performed by a qualified person under optimal conditions and results must be fully recorded.

4.2 - FUNCTIONAL TEST

Functional tests have confirmed the following: :

- The machine has performed all movements without jerking, while carrying the nominal load.
- All security systems are operating correctly.
- Maximum authorized operating speeds are not exceeded.

G

- Technical characteristics


4.3 - STABILITY TEST

The stability test proves that the machine is stable in an unfavourable position. The moment when the machine tips is calculated by combining loads in the machine's most unfavourable position (load W applied over distance L).

Stability table for HA12IP ()

	T (°)	W		L		Moment of tipping over
		Pound (lb)	Kilogramme (kg)	Feet inch (ft in)	Mètre (m)	daNm
Horizontal	3,5	761	345	18-11	5,76	1992

Stability for HA12IP ()




G

- Technical characteristics

Stability table for HA15IP ()

	T (°)	W		L		Moment of tipping over
		Pound (lb)	Kilogramme (kg)	Feet inch (ft in)	Mètre (m)	daNm
Horizontal	3,5	759	344	25-3	7.684	2646

Stability for HA15IP ()



G

- Technical characteristics

A

B

C

D

E

F

G


H

I

Stability table for HA16PE ()

	T (°)	W		L		Moment of tipping over
		Pound (lb)	Kilogramme (kg)	Feet inch (ft in)	Mètre (m)	daNm
Horizontal	3,5	789	358	27-6	8.381	3003

Stability for HA16PE ()




G - Technical characteristics

Stability table for HA12CJ (HA33CJ)

	T (°)	W		L		Moment of tipping over
		Pound (lb)	Kilogramme (kg)	Feet inch (ft in)	Mètre (m)	daNm
W1	3,5	662	300	19 ft 9 in	6,01	2112
W2	3,5	117	53	18 ft 11 in	5,76	2112

Stability for HA12CJ (HA33CJ)




G

- Technical characteristics

Stability table for HA12CJ+ (HA33CJ+)

	T (°)	W		L		Moment of tipping over
		Pound (lb)	Kilogramme (kg)	Feet inch ft in	Mètre (m)	daNm
W1	3,5	634	287,50	20 ft 7 in	6,28	2060
W2	3,5	97	44	18 ft 11 in	5,76	2060

Stability for HA12CJ+ (HA33CJ+)



See paragraph 1.12.2 of the AS1418.10 standard for test details.

The machine must return to a stable state without tipping over.

G

- Technical characteristics

5 - Declaration of conformity



CE Declarations of Conformity only apply to machines that are certified for the European market.

Declaration of conformity - Electric platforms

DECLARATION DE CONFORMITE CE

(certificate of conformity with CE-directives)

Nom et adresse du constructeur ou son représentant autorisé dans la communauté :
(Name and address of manufacturer or their authorised agents within the European Community)

HAULOTTE Group Siège Social
La Péronnière
BP 09
42152 L'HORME Cedex
FRANCE

HAULOTTE GROUP
Usine de _____

Déclare que la machine décrite ci-dessous :
(Declares that the technical installation described below)

Nacelle ou Plate-forme mobile élévatrice de personnes

(Elevating work Platform)

Machine au nom commercial (Machine with the commercial name) _____,
Conforme au type (in compliance with the type) _____
Numéro de série (Serial number): _____

Se conforme aux dispositions de la directive machine 2006/42/CE.
(Conforms to the provisions set out in the EC Machinery Directive 2006/42/EC)

N° de certificat (Certificate no): _____

Cette machine est identique au modèle ayant fait l'objet d'un examen CE de type par l'organisme notifié :
(This machinery is identical to the model that was tested in an EC type-examination by the appointed body)

Organisme certifié (Authorised certification body) :

_____ n° _____

- Se conforme également aux dispositions de la directive 2004/108/CE concernant la compatibilité électromagnétique.
(is in accordance with the provisions contained in EEC Directive no. 2004/108/CE on electromagnetic compatibility)
- Se conforme aux principales exigences des normes harmonisées suivantes : EN 280 et EN 954.
(also fulfils the principal requirements of the following harmonised standards: EN 280 and EN 954)

Fait à L'Horme le :

Directeur Division _____ /Managing Director, _____ Division

Signature

Cette déclaration est conforme aux exigences de l'annexe II-a de la directive 2006/42/CE. Toute modification de la machine décrite ci-dessus rendrait cette déclaration caduque.
This declaration conforms with the requirements of annex II-A of the directive 2006/42/EEC. Any modification to the above described machine violates the validity of this declaration.

G

- Technical characteristics

Declaration of conformity - Thermal platforms

DECLARATION DE CONFORMITE CE

(certificate of conformity with EC directives)

Nom et adresse du constructeur ou son représentant autorisé dans la communauté :
Name and address of manufacturer or their authorised agents within the European Community

HAULOTTE Group Siège Social
La Péronnière
BP 09
42152 L'HORME Cedex
FRANCE

HAULOTTE GROUP
Usine de _____

Déclare que la machine décrite ci-dessous :
(Declares that the technical installation described below)

Nacelle ou Plate-forme mobile élévatrice de personnes (Elevating work Platform)

Machine au nom commercial (Machine with the commercial name) _____,
Conforme au type (in compliance with the type) _____
Numéro de série (Serial number): _____

Se conforme aux dispositions de la directive machine 2006/42/CE.
(Conforms to the provisions set out in the EC Machinery Directive 2006/42/EC)

N° de certificat (Certificate no): _____

Cette machine est identique au modèle ayant fait l'objet d'un examen CE de type par l'organisme notifié :
(This machinery is identical to the model that was tested in an EC type-examination by the appointed body)

Organisme certifié (Authorised certification body) :

_____ n° _____

- Se conforme également aux dispositions de la directive 2000/14/CE concernant l'émission de bruit par l'équipement dans l'environnement en utilisation extérieure
(is also in accordance with the clauses contained in the EC Outdoor Noise Directive (2000/14/EC))

- Méthode de mesure (Measuring methods)	Annexe III-B
- L _{WA} , Niveau de puissance acoustique garantie (L _{WA} , sound level guaranteed)	_____ dB
- L _{WA} , Niveau de puissance acoustique minimum/maximum (L _{WA} , maxi sound level)	_____ / _____ dB
- Se conforme également aux dispositions de la directive 2004/108/CE concernant la compatibilité électromagnétique.
(is in accordance with the provisions contained in EEC Directive no. 2004/108/CE on electromagnetic compatibility)
- Se conforme aux principales exigences des normes harmonisées suivantes : EN 280 et EN 954.
(also fulfils the principal requirements of the following harmonised standards: EN 280 and EN 954)

Fait à L'Horme le :

Directeur Division _____ /Managing Director, _____ Division

Signature

Cette déclaration est conforme aux exigences de l'annexe II-A de la directive 2006/42/CE. Toute modification de la machine décrite ci-dessus rendrait cette déclaration caduque.
This declaration conforms with the requirements of annex II-A of the directive 2006/42/EEC. Any modification to the above described machine violates the validity of this declaration.

G - Technical characteristics

H

 - Intervention register

1 - Intervention register

In order to benefit from the HAULOTTE® guarantee, each maintenance or repair operation must be entered in the INTERVENTION REGISTER, which can be found at the end of the maintenance book delivered with your machine.

Intervention register

REGISTRE D'INTERVENTION HAULOTTE SERVICE

Date	Nature de l'intervention	Nombre heures	Intervenant	N° Intervention Haulotte service

H

- Intervention register